


















Position	Code	description
1= 2.1	3316N402S	Cooktop
2= 2.2	3426N40002	Manifold
3= 2.3	001057	Stainless steel screw
4= 2.4	003060	Snap ring
5= 2.5	211022	Pivot
6= 2.6	103572	Rear spacing
7= 2.7	51B6N01	Burners support
8= 2.8	027015	Inlet pipe plug
10= 2.10	094254	CLAMP
11= 2.11	001227	SCREW
12= 2.15	217510	Pan-support
13= 2.16	103298/NS	PLUG
14= 2.17	217299	Wok support
15= 2.23	001234.1	Stainless steel screw V
16= 3.1	35N6P22UDA	CONTROL PANEL
17= 3.2	103761	Control panel trim
18= 3.8	213007	CLIP
19= 4.1	4506N1SV11	Oven frame
20= 4.2	36C6NS1S	Left side panel
21= 4.3	36C6ND1S	Right side panel
22= 4.4	030082.1	Oven insulation
23= 4.5	030098.1	Rear insulation
24= 4.6	094354DX	Rear right coupler
25= 4.7	094354SX	Left right coupler
26= 4.8	4116N01	REAR PANEL
27= 4.9	4216107Z	Upper shelter
28= 4.10	103410080	SHIM
29= 4.11	040011	BUFFER
30= 4.13	053199	Bottom oven seal
31= 4.14	094333DX	Rear right coupler
32= 4.15	094333SX	Rear left coupler
33= 4.17	214056	Shim nut
34= 4.18	103160061	Base panel
35= 4.23	39E6603U	Drawer front panel
36= 4.29	531533	TUBE RETAINER
37= 4.30	68061010	Plinth
38= 4.32	4219604Z	Rear insulation support

39= 4.36	094098	Front panel right bracket
40= 4.37	094099	Front panel left bracket
41= 4.38	081083/NS	Right stopper
42= 4.39	081084/NS	Left stopper
43= 4.44	053074	Upper seal
44= 4.45	079017	Tangential fan
45= 4.46	46A6N03Z	Air conveyor
46= 4.47	46A6N02Z	FUNNEL
47= 4.48	094649	Anti-tilt bracket
48= 5.1	032612323	DOOR GLASS
49= 5.2	103713	Door handle plaque
50= 5.3	037191062	HANDLE
51= 5.4	4116111	Fixing bar
52= 5.5	001056	SCREW
53= 5.6	001071	Door handle screw
54= 5.8	063053	Door hinge (male)
55= 5.9	063025	Top oven hinge (female) works with male hinge 063089
56= 5.10	373FF719G	Door panel
57= 5.11	053084	Bottom oven glass seal
58= 5.12	0311000.1	Inner glass
59= 5.14	214021	NUT
60= 5.15	001214	SCREW
61= 5.16	003035	WASHER
62= 5.17	103205.1	WASHER
63= 5.21	003030	WASHER
64= 6.1	2183009465	Burner knob
65= 6.4a	106266	Tap diam 0.28 A
66= 6.4b	106267	Tap diam 0.33 SR
67= 6.4c	106269	Tap diam 0.63
68= 6.5	001282	Tap fixing screw
69= 6.6	094653	Tap bracket
70= 6.8a	215465	Burner-cupA
71= 6.8b	215466	Burner-cupSR
72= 6.9a	068110001	Burner-head SR
73= 6.9b	068109001	Burner-head A
74= 6.10a	216129080	Burner-cap A
75= 6.10b	216130080	Burner-cap SR

76= 6.11	103468	Test point adaptor
77= 6.12a	101182	Injector NATURAL GAS Ø 0.85 - A
78= 6.12b	101260	Injector NATURAL GAS Ø 1.12 - SR
79= 6.12c	101335	Injector NATURAL GAS Ø 1.60 - TR
80= 6.12d	101233	Injector ULPG Ø 0.95 - TR
81= 6.12e	101262	Injector ULPG Ø 0.53 - A
82= 6.12f	101263	Injector ULPG Ø 0.70 - SR
83= 6.14	053024.1	Sealing washer
84= 6.15	215469	Burner-cup Triple-ring
85= 6.16	103347	Gas pressure regulator 1/2
86= 6.17	067026	Conical adaptor
87= 6.18	027013	NG connection
88= 6.19	029600	Inlet pipe A
89= 6.20	029602	Inlet pipe left SR
90= 6.21	029601	Inlet pipe right SR
91= 6.22	029604	Inlet pipe TR
92= 6.35	068112001	TR burner head
93= 6.36	216132080	Burner-cap inside TR
94= 6.37	216133080	Burner-cap outside TR
95= 6.38	053078	Triple-ring burner-cup gasket
96= 6.39	040064	STOPPER
97= 7.1	217291	Shelf support
98= 7.3	48B6101G	DRIP PAN
99= 7.4	217439	OVEN SHELF
100= 7.7	217397	Grill-pan grid
101= 7.8	037144	Grill pan grid handle
102=8.13	214063	NUT
103=8.14	103210.1	Oven switch support
104=8.15	050030	Oven switch
105=8.16	066072	Oven thermostat
106=8.17	062158004	Top + grill element 230V
107=8.18	062066004	Bottom element 230V
108=8.19	030083.1	Bottom element insulation
109=8.20	4216102Z	Bottom element support
110=8.23	47AN601G	Fan diffuser
111=8.24	079008001F	Fan motor - 230 V
112=8.25	103085	FILTER
113=8.27	213025	CLIP

114=9.1	2183009464	KNOB
115=9.4	074012	Timer 120 min
116=11.1	072023	Lamp holder assembly
117=11.2	073013001	LAMP
118=11.5	082082	Electronic ignition
119=11.7	035094	Igniter spring
120=11.8	084029	Spark plug L=630mm (semirapid &
121=11.8	084033	Igniter TR - L = 500
122=11.11	103230.1A	Terminal block protection
123=11.13	041210	Earth plate
124=11.14	052008	Cable clamp - rear cooker
125=11.15	054041	CORD
126=11.16	1131792	WIRING
127=11.18	1031252	Ignition switches
128=11.19	035080	Ignition switches spring
129=11.20	003039	RETAINING RING
130=11.21	003038	WASHER
131=11.22	094221	Earth plate
132=11.30	066057	Cut-off thermostat
133=11.32	051049	Terminal block 25A-3P
134=11.33	073090	Control lamp cover (Blue)
135=11.34	073091	Control lamp L = 230