



















Position	Code	description
0= 00	630F612	Oven condensation kit
1= 1.1	630F617	Control panel assembly (INCLUDING buttons and frame REF. 2.22+ 2.23+ 2.24+ 2.25)
2= 1.2	450F31ES41	Oven Cube
3= 1.3	K544511	Oven Cube
4= 1.8	053102	Top oven seal
5= 1.9	035101	Insulation spring
6= 1.10	51BF613	Oven body bar
7= 1.12	51BF614S.1	Deflector
8= 1.13	51BFD01DS	Right front trim
9= 1.14	51BFD01SS	Left front trim
10= 1.15	411FDD1Z	Right side panel
11= 1.16	411FDS1Z	Left side panel
12= 1.17	411F602.1	Bottom panel
13= 1.18	08328400A	Lower trim
14= 1.19	094390	Door hinge (female)
15= 1.20	030140.1	Top oven rear insulation
16= 1.21	030200	Rear insulation
17= 1.22	030139.1	Top oven insulation
18= 1.23	030120.1	Oven insulation
19= 1.24	030190.1	Side lamp insulation
20= 1.25	035097	Rotisserie hole plug
21= 1.27	040056	Rubber
22= 1.28	103672	WIRE CLAMP
23= 1.30	411FD01	REAR PANEL
24= 1.31	411F604	Upper shelter
25= 1.32	51BF609	Terminal block shield
26= 1.33	51BF612H	Top oven body panel
27= 1.34	053074	Upper seal
28= 1.35	053087	SEAL
29= 1.36	094620	Terminal block support
30= 1.37	094392	Thermal overload support
31= 1.40	079017	Tangential fan
32= 1.46	411FD02	Bottom air conveyor
33= 1.47	421F602Z	Conveyor support
34= 1.48	411F605	Air conveyor
35= 2.2	032F2717DA	DOOR GLASS

36= 2.3	0312578TH	Inner glass
37= 2.4	063112	Hinge (male)
38= 2.5	51AF303SH	Left door trim
39= 2.6	51AF303DH	Right door trim
40= 2.7	037241062	Door handle
41= 2.8	053125	SEAL
43= 2.10	51BF623A	Handle bar
45= 2.15	062115004	Top + grill element - 230V
46= 2.16	213023	CLIP
47= 2.17	062105004	Bottom element 230 V
48= 2.18	51BF603	Bottom element support
49= 2.21	050040.1	Oven switch
50= 2.22	066157	THERMOSTAT
52= 2.26	217648	Shelf support
55= 2.31	094516	Hook support
56= 2.32	534186	HOOK
57= 2.1	218900A463	CONTROL KNOB
58= 2.2	050028.1	Oven switch
59= 2.3	066078	THERMOSTAT
60= 2.7	213025	CLIP
61= 2.21	074069	Electronic programmer
62= 2.22	1031216	Pivot button (please order complete control panel)
63= 2.23	035111	Spring Plate (please order the complete control panel)
64= 2.24	10312130A	Consolle frame (please order complete control panel)
65= 2.25	103121207	Button (please order complete control panel)
66= 2.26	094648	Electronic programmer bracket
67= 3.20	103085	FILTER
68= 3.27	062098004	Top + grill element 230V
69= 3.28	062090004	Bottom element - 230 V
70= 3.29	062097004	Fan element
72= 3.31	079008001F	Fan motor - 230 V
73= 3.32	030136.1	Fan motor insulation
74= 3.35	47AF6010	Fan diffuser
75= 3.36	217647	Shelf support
76= 3.37	001142	Shelf support screw
77= 3.38	48BF601G	Oven tray
78= 3.39	103406	Kit pizza stone
79= 3.40	217551.1	WIRE SHELF

80= 3.41	217558.2	WIRE SHELF
81= 3.42	217546	Grill-pan grid
82= 3.43	037144	Grill pan grid handle
83= 3.44	1031037	Right telescopic runner
84= 3.45	1031038	Left telescopic runner
85= 3.46	473070	Lateral catalytic panel
86= 3.47	473100	Left lateral catalytic panel
87= 3.48	48EF601	Pastry plate
88= 3.1	032F2716DA	DOOR GLASS
89= 3.2	0313241TH	Inner glass
90= 3.3	0312570TH	Intermediate glass
91= 3.4	063120	Hinge (male)
92= 3.5	51AF621SA	Left door trim
93= 3.6	51AF621DA	Right door trim
96= 3.10	51BF625H	Handle bar
97= 3.11	001265	Door handle screw
98= 3.12	001270	SCREW
99= 3.13	1031052	Top middle glass clamp
100= 3.14	1031053	Bottom middle glass clamp
101= 4.19	073092	Control lamp cover
102= 4.20	073091	Control lamp L = 230
103= 4.25a	066068	Cut-off thermostat 130 degree
104= 4.25b	066140	Cut-off thermostat 175 degree
105= 4.25c	066080	Cut-off thermostat 55 degree
106= 4.26	072006	LAMP HOLDER
107= 4.28	073013001	LAMP
108= 4.27	072015	Side lamp holde
109= 4.29	051062	Terminal block
110= 4.30	052008	Cable clamp - rear cooker
111= 4.32	052007	Wire ring
112= 4.31	1131799	WIRING
113= 4.33	1131595	Electronic cards wiring (Side lamp)