























Position	Code	description
0= 00a	6300050	Kit TCO 160 degree
0= 00b	6300055	Kit fan run on limiter
0= 00c	1031019	Silicon sleeve
0= 00d	6300021	Fan resistor kit
0= 00e	040066	Rubber pad (for trivets)
1= 1.1	103630063	Rear trim
2= 1.5	040041001	PLUG
3= 1.6	001007	Vis
4= 2.1	3429S50001	Manifold
5= 2.2	3319S501S	Cooktop
6= 2.5	51B9S01	Burners support
7= 2.6	027015	Inlet pipe plug
8= 2.11	217498	Grid for woks
10= 2.13	103615	PIN
11= 2.14	035100	SPRING
12= 2.15	217530	Pan-support
13= 2.16	217533	Pan-support
14= 2.17	214062	NUT
15= 2.18	094473	Fixing plate
16= 2.19	217303	Grate for small pans
17= 2.20	51B9S05	Cross-piece
18= 2.24	001234.1	Stainless steel screw V
19= 2.26	001167	SCREW
20= 3.1	6309S11	CONTROL PANEL ASSEMBLY
21= 3.2	103760	Control panel trim
22= 3.8	213007	CLIP
23= 4.4	030074.1	Oven insulation
24= 4.5	030106.1	Rear insulation
25= 4.6	094417DX	Rear hob support right
26= 4.7	094417SX	Rear hob support left
27= 4.8	4119602	REAR PANEL
28= 4.9	4219S01Z	Upper shelter
29= 4.13	053101	SEAL
30= 4.18	1031295.1	SHIM L.150-180
31= 4.20	040061	BUFFER
32= 4.21	063075	HINGE
33= 4.23	371V9601L	FRONT PANEL

34= 4.24	373V9601Y	Inside panel
35= 4.25	36C96D1S	Side panel right
36= 4.26	36C96S1S	Side panel left
37= 4.27	094226	BRACKET
38= 4.31	094412	BRACKET
39= 4.32	4219604Z	Rear insulation support
40= 4.34	103505A	Rotisserie motor support
41= 4.36	081084/NS	Left stopper
42= 4.37	081083/NS	Right stopper
43= 4.38	46A9S02Z	Air conveyor
44= 4.39	46A9S01Z	FUNNEL
45= 4.40	079025	Tangential fan
46= 4.41	053092	Funnel gasket
47= 4.42	040056	Rubber
48= 4.47	1031207	Lock pin
49= 4.48	094153	Anti tilt bracket
50= 4.50	45EN6106P	Left oven side panel (Left)
51= 4.51	45E96001P	Top oven panel
52= 4.52	45EN6107P	Left oven side panel (Right)
53= 4.53	45H96008P	BODY REAR PANEL
54= 4.55	45B96003P	Body front panel
55= 4.56	45K96004Z	Lower element cover
56= 4.57	211012	RIVET
57= 5.1	032962749A	DOOR GLASS
58= 5.3	037195062	Door handle
59= 5.5	003057	WASHER
60= 5.6	001083	SCREW
61= 5.8	063100	Door hinge (male)
62= 5.9	063066	Top oven hinge (female) works with male hinge 063096
63= 5.10	373F9604G	INNER DOOR
64= 5.11	053058	GASKET
65= 5.12	0311292/TH	Inner glass
66= 5.14	214021	NUT
67= 5.15	001143	SCREW
68= 5.16	003035	WASHER
69= 5.17	103205.1	WASHER
70= 5.23	053083	GASKET

71= 5.24	213029	CLIP
72= 5.26	001089	SCREW
74= 6.1	2183009462	Burner knob
75= 6.4a	106236	Tap diam 0.27 A
76= 6.4b	106237	Tap diameter 0.32
77= 6.4c	106239	Tap diameter 0.65 TR
78= 6.5	001233	Tap fixing screw
79= 6.6	094382	Tap bracket
80= 6.8A	215465	Burner-cupA
81= 6.8SR	215466	Burner-cupSR
82= 6.8PE	215471	Burner-cup (fish)
83= 6.9SR	068110003	Burner-head Semi-rapid
84= 6.9A	068109003	Burner-head Auxiliary
85= 6.10A	216129005A	Burner-capA
86= 6.10SR	216130005A	Burner-capSR
87= 6.12a	101182	Injector NATURAL GAS Ø 0.85 - A
88= 6.12b	101273	Injector Rapid diam 1.45 - NG
89= 6.12c	101260	Injector NATURAL GAS Ø 1.12 - SR
90= 6.12d	101244	Injector Rapid diam 0.91 - LPG
91= 6.12e	101262	Injector ULPG Ø 0.53 - A
92= 6.12f	101263	Injector ULPG Ø 0.70 - SR
93= 6.14	053024.1	Sealing washer
94= 6.15	215469	Burner-cup Triple-ring
95= 6.16	103347	Gas pressure regulator 1/2
96= 6.17a	101261	Injector - diameter 1.65 TR - Natural gas
97= 6.17b	101233	Injector ULPG Ø 0.95 - TR
98= 6.19	029633	Inlet pipe - front right A
99= 6.20	029632	Inlet pipe - rear right SR
100= 6.22	029631	FB inlet pipe - central
101= 6.23	029630	Inlet pipe - rear left SR
102= 6.24	029629	Inlet pipe - front left TR
103= 6.25	068112003	TR burner head
104= 6.26a	107039	Burner thermocouple L=500 mm
105= 6.26b	107039	Burner thermocouple L=500 mm
106= 6.26c	107043	Burner thermocouple L=500mm (triple-ring burner)
107= 6.27	214057	NUT
108= 6.28	027013	NG connection
109= 6.29	067026	Conical adaptor

110= 6.30	103468	Test point adaptor
111= 6.36	216132005A	Burner-cap inside TR
112= 6.37	216133005A	Burner-cap outside TR
113= 6.38	053078	Triple-ring burner-cup gasket
114= 6.40	0681140035	Fish-burner
115= 7.1	217590DX	Right shelf support
116= 7.2	217590SX	Left shelf support
117= 7.3	48B8501P	Oven tray
118= 7.4	217601	OVEN SHELF
119= 7.5	217600	Oven tray support
120= 7.6	47E9604G	Oven floor
121= 7.7	037208	Grill-pan grid handle
122= 7.8	217523	Grill-pan grid
123= 7.10a	080035	Rotisserie spear (without handle)
123= 7.10b	037012	Spear handle
124= 7.11	079014	Rotisserie motor
125= 7.12	217599	Rotisserie support
126= 7.14	473000	Catalytic panels
127= 7.16	103406	Kit pizza stone
128= 8.1	2183009461	Knob hi-light cooking zone
130= 8.15	050028.1	Oven switch
131= 8.16	066072	Oven thermostat
132= 8.17	062075004	Top element 230V
133= 8.18	062073004	Bottom element 230V
134= 8.19	030076.1	Bottom element insulation
135= 8.20	4219602Z	Bottom insulation support
136= 8.21	4219605Z	Bottom element support
137= 8.22	103085	FILTER
138= 8.23	47A96010.2	Fan diffuser
139= 8.24	079008001F	Fan motor - 230 V
140= 8.26	062057004	Fan element - 230 V
141= 8.27	213025	CLIP
142= 9.1	074069	Electronic programmer
143= 9.6	094647	Electronic programmer bracket
144= 11.1	072025	Lamp holder assembly
145= 11.2	073013001	LAMP
146= 11.5	082095	Electronic Ignition
147= 11.7	035094	Igniter spring

148= 11.8a	084029	Spark plug L=630mm (semirapid &
149= 11.8b	084035	Igniter TR - L = 900
150= 11.8c	084036	Igniter L = 900
151= 11.11	103230.1A	Terminal block protection
152= 11.14	052008	Cable clamp - rear cooker
153= 11.15	054041	CORD
154= 11.16	1131793	WIRING
155= 11.18	103664	Ignition switches
156= 11.19	035080	Ignition switches spring
157= 11.20	003039	RETAINING RING
158= 11.21	003038	WASHER
159= 11.22	050058	Knob switch
160= 11.23	085081	Knob sleeve
162= 11.32	051049	Terminal block 25A-3P
163= 11.33	073090	Control lamp cover (Blue)
164= 11.34	073091	Control lamp L = 230
165= 11.36	066190	CUT-OFF THERMOSTAT