






























Position	Code	description
0= 00a	1031019	Silicon sleeve
0= 00b	6300021	Fan resistor kit
1= 1.1	103630063	Rear trim
2= 1.5	040041001	PLUG
3= 1.6	001007	Vis
4= 2.1	3429S50001	Manifold
5= 2.2	3319S502S	Cooktop
6= 2.5	51B9S01	Burners support
7= 2.6	027015	Inlet pipe plug
8= 2.12	053024.1	Sealing washer
9= 2.13	103615	PIN
10= 2.14	035100	SPRING
11= 2.15	217530	Pan-support
12= 2.16	217534	Central pan support
13= 2.17	214062	NUT
14= 2.18	094473	Fixing plate
15= 2.19	217303	Grate for small pans
16= 2.20	51B9S05	Cross-piece
17= 2.23	001234.1	Stainless steel screw V
18= 2.26	001167	SCREW
19= 2.27	217498	Grid for woks
20= 3.1	35N9184UDA	CONTROL PANEL
21= 3.2	103760	Control panel trim
22= 3.8	213007	CLIP
23= 4.4	030074.1	Oven insulation
24= 4.5	030106.1	Rear insulation
25= 4.6	094417DX	Rear hob support right
26= 4.7	094417SX	Rear hob support left
27= 4.8	4119602	REAR PANEL
28= 4.9	4219S01Z	Upper shelter
29= 4.11	053095	Top seal
30= 4.13	053101	SEAL
31= 4.18	1031295.1	SHIM L.150-180
32= 4.20	040061	BUFFER
33= 4.21	063075	HINGE
34= 4.23	371V9601L	FRONT PANEL
35= 4.24	373V9601A	Inside panel

36= 4.25	36C96D1S	Side panel right
37= 4.26	36C96S1S	Side panel left
38= 4.31	094412	BRACKET
39= 4.32	4219604Z	Rear insulation support
40= 4.34	035097	Rotisserie hole plug
41= 4.36	081084/NS	Left stopper
42= 4.37	081083/NS	Right stopper
43= 4.38	46A9S02Z	Air conveyor
44= 4.39	46A9S01Z	FUNNEL
45= 4.40	079025	Tangential fan
46= 4.41	053092	Funnel gasket
48= 4.47	1031207	Lock pin
49= 4.48	094153	Anti tilt bracket
50= 4.50	45EN6106K	Oven side panel (Left)
51= 4.51	45E96001K	Top oven panel
52= 4.52	45EN6107K	Oven side panel (Right)
53= 4.53	45H96005G	BODY REAR PANEL
54= 4.55	45B96003G	Body front panel
55= 4.56	45K96004Z	Lower element cover
56= 4.57	211012	RIVET
57= 5.1	0312662	DOOR GLASS
58= 5.2	083240061	Lower door trim
59= 5.3	037195062	Door handle
60= 5.4	51B9605	Handle trim
61= 5.5	003057	WASHER
62= 5.6	103890080	Door handle plaque
63= 5.7	001030	SCREW
64= 5.8	063073	Door hinge (male)
65= 5.9	063066	Top oven hinge (female) works with male hinge 063096
66= 5.10	373F9605G	Door panel
67= 5.11	053058	GASKET
68= 5.12	0311292/TH	Inner glass
69= 5.14	214021	NUT
70= 5.15	001143	SCREW
71= 5.16	003035	WASHER
72= 5.17	103205.1	WASHER
73= 5.21	003030	WASHER

74= 5.23	001056	SCREW
75= 6.1	2183009462	Burner knob
76= 6.4a	106240	Tap - diameter 0.28 A
77= 6.4b	106241	Tap - diameter 0.33 SR
78= 6.4c	106242	Tap - diameter 0.43 R
79= 6.4d	106243	Tap - diameter 0.63 TR
80= 6.5	001233	Tap fixing screw
81= 6.6	094382	Tap bracket
82= 6.8A	215465	Burner-cupA
83= 6.8SR	215466	Burner-cupSR
84= 6.8R	215467	Burner-cupTR
85= 6.9R	216129005A	Burner-capA
86= 6.9SR	216130005A	Burner-capSR
87= 6.9A	216131005A	Burner-cap R
88= 6.12a	101182	Injector NATURAL GAS Ø 0.85 - A
89= 6.12b	101273	Injector Rapid diam 1.45 - NG
90= 6.12c	101260	Injector NATURAL GAS Ø 1.12 - SR
91= 6.12d	101244	Injector Rapid diam 0.91 - LPG
92= 6.12e	101262	Injector ULPG Ø 0.53 - A
93= 6.12f	101263	Injector ULPG Ø 0.70 - SR
95= 6.15	215469	Burner-cup Triple-ring
96= 6.17a	101261	Injector - diameter 1.65 TR - Natural gas
97= 6.17b	101233	Injector ULPG Ø 0.95 - TR
98= 6.19	029626	Inlet pipe - front right A
99= 6.20	029625	Inlet pipe - rear right SR
100= 6.21	029634	Inlet pipe - central TR
101= 6.22	029635	Inlet pipe - front left R
102= 6.23	029622	Inlet pipe - rear left SR
103= 6.25	068112001	TR burner head
104= 6.28	027013	NG connection
105= 6.30	103347	Gas pressure regulator 1/2
106= 6.31	103468	Test point adaptor
107= 6.32	067026	Conical adaptor
108= 6.36	216132005A	Burner-cap inside TR
109= 6.37	216133005A	Burner-cap outside TR
110= 6.38	053078	Triple-ring burner-cup gasket
111= 6.39	040064	STOPPER
112= 7.1	217291	Shelf support

113= 7.2	217497	Oven tray support
114= 7.3	48B8501G	Oven tray
115= 7.4	217626	OVEN SHELF
116= 7.6	47E9604G	Oven floor
117= 7.7	037208	Grill-pan grid handle
118= 7.8	217523	Grill-pan grid
120= 8.1	2183009461	Knob hi-light cooking zone
121= 8.3	085081	Knob sleeve
122= 8.15	050030	Oven switch
123= 8.16	066072	Oven thermostat
124= 8.17	062075004	Top element 230V
125= 8.18	062073004	Bottom element 230V
126= 8.19	030076.1	Bottom element insulation
127= 8.20	4219602Z	Bottom insulation support
128= 8.21	4219605Z	Bottom element support
129= 8.22	103085	FILTER
130= 8.23	47A9601K.2	Fan diffuser
131= 8.24	079008001F	Fan motor - 230 V
132= 8.27	213025	CLIP
133= 8.28	094395	Plaque
134= 9.1	074069	Electronic programmer
135= 9.2	094363	Electronic timer seal
136= 9.3	103376007	Button
137= 9.4	040056	Rubber
138= 11.1	072025	Lamp holder assembly
139= 11.2	073013001	LAMP
140= 11.5	082095	Electronic Ignition
141= 11.7	035094	Igniter spring
142= 11.8a	084029	Spark plug L=630mm (semirapid &
143= 11.8b	084033	Igniter TR - L = 500
144= 11.8c	084036	Igniter L = 900
145= 11.11	103230.1A	Terminal block protection
146= 11.14	052008	Cable clamp - rear cooker
147= 11.15	054041	CORD
148= 11.16	1131791	WIRING
149= 11.18	103664	Ignition switches
150= 11.19	035080	Ignition switches spring
151= 11.20	003039	RETAINING RING

152= 11.21	003038	WASHER
153= 11.32	051049	Terminal block 25A-3P
154= 11.33	073090	Control lamp cover (Blue)
155= 11.34	073091	Control lamp L = 230
156= 11.36	066123	Cut-out thermostat 160 degree C