










Position	Code	description
1= 1.1	0329E005	Glass facia panel
2= 1.2	218900A463	CONTROL KNOB
3= 1.3	074103	PROGRAMMER
4= 1.4	040056	Rubber
5= 1.5	07306202.2	Control lamp cover (Red)
6= 1.6	35M9E003A	INTERIOR CONTROL PANEL
7= 1.7	094657	BRACKET
8= 1.8	050062	Oven switch (see tech bulletin AUNZ0155 for wiring connections)
9= 1.9	066078	THERMOSTAT
10= 1.10	0329E006	OVEN DOOR GLASS
11= 1.11	037297062	OVEN DOOR HANDLE
12= 1.12	0312813	INNER DOOR GLASS
13= 1.13	063128	Hinge Male
14= 1.14	069096	Corner door lower left
15= 1.15	069097	Retainer door glass
16= 1.16	069098	Support door glass
17= 1.17	069095	Corner door lower right
18= 1.18	51BF904H	LOWER BAR
19= 1.19a	073039.2	Control lamp L 230
20= 1.19b	073044.2	Control lamp L 600/240
21= 2.1	411F902	UPPER SHELTER
22= 2.2	421F909Z	PANEL VENTING MIDDLE
23= 2.3	421F905Z	LOWER SHELTER
24= 2.4	079054	TANGENTIAL FAN
25= 2.5	08333200H	TOP TRIM
26= 2.6	040041001	PLUG
27= 2.7	1031234	SPACER
28= 2.8	214005	NUT
29= 2.9	08333300H	MIDDLE TRIM
30= 2.10	08333400H	LOWER TRIM
31= 2.11	450F91EM42	Oven frame
32= 2.12	094673	BRACKET
33= 2.13	030219	Oven insulation
34= 2.14	030220	REAR INSULATION
35= 2.15	421F910Z	Rear inner panel
36= 2.16	411F903	REAR SHELTER

37= 2.17	411F905	LEFT SIDE PANEL
38= 2.18	51BF906A	FRONT TRIM
39= 2.19	45BF9002P	BODY FRONT PANEL
40= 2.20	053146	SEAL
41= 2.21	08333100A	LOWER TRIM
42= 2.22	063127	FEMALE HINGE
43= 2.23	1031280	BRACKET
44= 2.24	1031283	Element support
45= 2.25	421F908Z	LOWER PROTECTION
46= 2.26	51BF907	SUPPORT BAR
47= 2.27	411F901	LOWER SHELTER
48= 2.29	1031281	BRACKET
49= 2.30	001029	SCREW
50= 2.31	421F902Z	MOTOR SUPPORT
51= 2.32	35M9E002A	INTERIOR CONTROL PANEL
52= 2.33	411F904	Right side panel
53= 2.34	51BF905	Support bar
54= 2.35	47AF9020	Fan diffuser
55= 2.36	213026	CLIP
56= 2.38	051049	Terminal block 25A-3P
57= 2.39	051079	Terminal Block
58= 2.40	054120	Cord 3x1.5
59= 2.41a	066068	Cut-off thermostat 130 degree
60= 2.41b	066145	Cut-off thermostat 80 degrees
61= 3.1	217659	Shelf support
62= 3.2	217650	OVEN SHELF
63= 3.3	217657	FLAT SHELF
64= 3.4	48BF901P	Oven tray
65= 3.5	217651	Grill pan grid
66= 3.6	001142	Shelf support screw
67= 3.7	062157004	Top + grill element
68= 3.8	072026	LAMP HOLDER
69= 3.9	062146004	Bottom element
70= 3.10	1131872	WIRING
71= 3.11	062135004	Fan element 2.5 kw
72= 3.12	079008001F	Fan motor - 230 V
73= 3.13	037224.1	GRILL-PAN GRID HANDLE
74= 3.14	073004	LAMP

75= 3.15	103406	Kit pizza stone
76= 3.16	080036	Rotisserie spear
77= 3.17	217652	Rotisserie support
78= 3.18	085109	Rotisserie screw
79= 3.19	085110	Rotisserie bush
80= 3.20	1031782	Right telescopic runner
81= 3.21	1031783	LEFT TELESCOPIC RUNNER
82= 3.22	473140	RIGHT CATALYTIC PANEL
83= 3.23	473150	LEFT CATALYTIC PANEL
84= 3.24	094671	Equerre
85= 3.25	079053	Rotisserie motor
86= 3.26	094516	Hook support
87= 3.27	534186	HOOK
88= 3.28	103085	FILTER