














NZ, AU DE91PYROS

Position	Code	description
0= 0.0	073103	LAMP
1= 1.1	218900A489	KNOB
2= 1.2	0329E017	GLASS FACIA PANEL
3= 1.3	1031274	Push-button
4= 1.4	040080	Rubber ring
5= 1.5	040056	Rubber
6= 1.6	214082	NUT
7= 1.7	1031269	Housing clock
8= 1.8	1031271	Reflector function
9= 1.9	1031272	Diffuser function
10= 1.10	1031273	Housing temp
11= 1.11	094657	BRACKET
12= 1.12	074109	Module clock
13= 1.13	074111	Module function
14= 1.14	074110	Module temperature
15= 1.15	040081	Insulator rubber
16= 1.16	050081	Encoders temperature+function
17= 1.17	1031464	Clock mask
18= 1.18	35M9E004H	INTERIOR CONTROL PANEL
19= 1.19	1131838	Harness clock function temperature
20= 1.20	0329E006	OVEN DOOR GLASS
21= 1.21	037297062	OVEN DOOR HANDLE
22= 1.22	0312810	Glass Door Middle
23= 1.23	0312809	Inner Door Glass
24= 1.24	063126	MALE HINGE
25= 1.25	069096	Corner door lower left
26= 1.26	069095	Corner door lower right
27= 1.27	069097	Retainer door glass
28= 1.28	069098	Support door glass
29= 1.29	51BF904H	LOWER BAR
30= 2.0	411F902	UPPER SHELTER
31= 2.1	421F906Z	Shelter
32= 2.2	421F907Z	Shelter
33= 2.3	079052	Tangential fan
34= 2.4	08333200H	TOP TRIM
35= 2.5	08333300H	MIDDLE TRIM
36= 2.6	08333400H	LOWER TRIM

NZ, AU DE91PYROS

37= 2.7	040041001	PLUG
38= 2.8	1031234	SPACER
39= 2.9	411F903	REAR SHELTER
40= 2.10	421F910Z	Rear inner panel
41= 2.11	51BFG01	MOTOR SUPPORT
42= 2.12	421F905Z	LOWER SHELTER
43= 2.13	094670	BRACKET
44= 2.14	094672	BRACKET
45= 2.15	094673	BRACKET
46= 2.16	094669	Fixing bracket
47= 2.17	51BF908	Service panel access
48= 2.18	1031284	TUBE
49= 2.19	1031285	FILTER
50= 2.20	1031289	FILTER
51= 2.21	030216	Oven insulation
52= 2.22	030221	REAR INSOLATION PANEL
53= 2.23	51BF905	Support bar
54= 2.24	411F905	LEFT SIDE PANEL
55= 2.25	411F906	RIGHT SIDE PANEL
56= 2.26	421F902Z	MOTOR SUPPORT
57= 2.27	51BF906A	FRONT TRIM
58= 2.28	421F901Z	Grill Reflector
59= 2.29	450F91EM34	OVEN CUBE
60= 2.30	063127	FEMALE HINGE
61= 2.31	1031281	BRACKET
63= 2.33	1031280	BRACKET
64= 2.34	47AF902P	FAN DIFFUSER
65= 2.35	45BF9002P	BODY FRONT PANEL
66= 2.36	053144	SEAL
67= 2.37	51BF907	SUPPORT BAR
68= 2.38	421F908Z	LOWER PROTECTION
69= 2.39	1031283	Element support
70= 2.40	411F901	LOWER SHELTER
71= 2.41	08333100A	LOWER TRIM
72= 2.42	074107	Module power
73= 2.43	071064	PIN
74= 2.44	066180	FUSE
75= 2.45	066176	Cut-off thermostat 85 degree

NZ, AU DE91PYROS

76= 2.46	35M9E002A	INTERIOR CONTROL PANEL
77= 2.47	051069	Terminal block
78= 2.48	054125	Cord
79= 3.0	094664	Bracket lock system
80= 3.1	052007	Wire ring
81= 3.2	1031277	TRIGGER DOOR SENSOR
82= 3.3	035113	SPRING
83= 3.4	085106	Pin pivot lock
84= 3.5	077085	Switch lock
85= 3.6	079051	Lock motor
86= 3.7	094662	Rocker lock
87= 3.8	094663	Linkage lock
88= 3.9	003078	Starlock washer
89= 3.10	003079	RETAINING RING
90= 3.11	071063	Pin linkage
91= 3.12	1031276	Rod actuator
92= 3.13	094665	Bracket hook
93= 3.14	094661	Hook lock
94= 3.15	085107	Lighting tube
95= 3.16	1131839	Harness lock switch
96= 3.17	1131840	Harness door switch
97= 4.0	107071	TEMPERATURE SENSOR
98= 4.1	213031	CLIP
99= 4.2	062134004	Top+grill element
100= 4.3	062135004	Fan element 2.5 kw
101= 4.4	062136004	Bottom element
102= 4.5	079023	FAN MOTOR
103= 4.6	072026	LAMP HOLDER
104= 4.7	1031286	Cooling fan element
105= 4.8	1031288	Rel&
106= 4.9	035118	WIRE STANDOFF COIL
107= 5.0	1131842	Harness power board clock
108= 5.1	1131844	Harness temp sensor
109= 5.2	1131843	Wiring main relay
110= 5.3	1131967	Light wiring
111= 5.4	1131841	Wiring mains loom
112= 5.8	003043	Retainig ring
113= 5.7	103057	LIGHTING TUBE

NZ, AU DE91PYROS

114= 5.9	079014	Rotisserie motor
115= 6.0	080036	Rotisserie spear
116= 6.1	217670	Rotisserie support
117= 6.2	217676	OVEN SHELF
118= 6.3	217651	Grill pan grid
119= 6.4	037224.1	GRILL-PAN GRID HANDLE
120= 6.5	48BF903P	OVEN TRAY
121= 6.6	103406	Kit pizza stone
122= 6.7	48EF904	PASTRY PLATE
123= 6.8	103085	FILTER