



























705




710



711

706



714




715



713

709



Position	Code	description
000a	DAU1591136	ADHESIVE for CONTROL PANEL
000b	DAU1591104	17176000000306-Turbidity transducer
101	DAU1591004	Retaining patch
102	DAU1591001	LAMP COVER
103	DAU1591000	HANDLE COVER
104+421	DAU1591007	PCB
105	DAU1590992	Button A
106	DAU1590991	Button B
107	DAU1590981	Control panel cover sticker (SEE also complete control panel position 107+108 p/n DAU1591120)
107+108	DAU1591120	CONTROL PANEL ASSY DEDW645S
108	DAU1590989	Control Panel without sticker (SEE also complete control panel 107+108)
109	DAU1590895	Out door
110	DAU1590996	Baseboard
201	DAU1590897	DOOR SWICTH ASSEMBLY
202	DAU1590988	Inner door assembly
203	DAU1590899	FRICTION STRIP HOOKING
204	DAU1590900	121760000003629-Friction strip hooking clamping
205	DAU1590984	122760000001731-Left hinge assembly
208	DAU1590773	DISPENSER BRACKET
209	DAU1590902	DISPENSER
210	DAU1590983	122760000001778-Right hinge assembly
211	DAU1590904	HINGE join board
301	DAU1590985	Left side panel
302	DAU1590986	Right side panel
303	DAU1591087	UPPER back support
305	DAU1590908	Cutlery shelf guider link stopper(back)
306	DAU1590909	Cutlery shelf guider(LEFT)
306a	DAU1590977	Cutlery shelf guider(RIGHT)
307	DAU1590910	TOP PANEL
309	DAU1591043	121760000010412-Rail support assembly
310	DAU1590912	121760000008444-Cutlery shelf guider supporting holder
311	DAU1591126	121760000010336-Cutlery shelf rail support assembly
313	DAU1590914	basket guider supporting holder
314	DAU1591002	Anti-Noise Borad
315	DAU1590916	UPPER BASKET guider link stopper(back

316	DAU1590917	UPPER BASKET guider (LEFT)
316a	DAU1590978	UPPER BASKET guider (RIGHT)
317	DAU1590918	TANK GASKET
319	DAU1590919	DOOR LOCK HOOK
320	DAU1590920	Back cover board
401	DAU1591005	Power cord
402	DAU1590922	12176000013663-Air breaker nut
403	DAU1590923	AIR BREAKER ASSEMBLY
405	DAU1590924	DRAIN pipe CLAMPING
408	DAU1590925	tub Support
409	DAU1591084	BASE
410	DAU1590927	FRICTION STRIP GUIDING
411	DAU1590928	Friction Strip
412	DAU1591106	DOOR SPRING
414	DAU1590930	adjust screw OF DOOR SPRING
417	DAU1591110	BASE COVER
418	DAU1591022	FOOT
419	DAU1590933	pcb seat cover
420	DAU1590934	pcb seat
423	DAU1590937	12876000000050-Float
425	DAU1590938	12176000003125-Overflow switch seat
427	DAU1590940	17476000001137-Overflow switch
428	DAU1590939	PRESSURE SWITCH
429	DAU1590997	Power Supply Loom Clamping
430	DAU1590941	12676000000138-Drain hose assembly
504	DAU1590942	INNER PIPE
507	DAU1591115	Water Dispenser Assembly
510	DAU1591111	Middle Spayer
511	DAU1591112	LOWER SPRAYER
512	DAU1590946	LOWER SPRAYER seat
513	DAU1591025	PLASTIC FILTER
601	DAU1590948	SUMP NUT
602	DAU1590949	SUMP GASKET
603	DAU1590950	PVC pipe
604	DAU1590995	SUMP Inlet hose
605	DAU1590966	DIVERTER
606	DAU1590967	DIVERTER GASKET
607	DAU1590951	SUMP ASSEMBLY

608	DAU1590952	INNER DRAIN pipe
611	DAU1590953	Drainage pump
612	DAU1591026	main filter
613	DAU1590955	Filter handle
614	DAU1590956	12176000003676-Cylinder filter
616	DAU1591009	WASH PUMP ASSEMBLY
619	DAU1590961	940 CLAMPING
621	DAU1590963	HEATING ELEMENTS ASSEMBLY
623	DAU1590964	WATER PRESSURE SWITCH ASSEMBLY
625	DAU1590965	17176000012008-Thermostat
705	DAU1590968	12176000002819-Cutlery assembly
706	DAU1591132	UPPER BASKET ASSY
709	DAU1591066	Lower Basket Assembly
710	DAU1590971	Inlet hose assembly
711	DAU1590972	Wiring harness
713	DAU1590973	basket Handle lid (front)
714	DAU1590974	basket Handle lid (back)
715	DAU1590980	BASKET HANDLE adhibit piece