







Position	Code	description
0b	DAU1591272	Lower basket fixed block
C5004	DAU1590870	rinsing agent cup
OTK 175	DAU1590739	OTK 175
OTK 192	DAU1590741	OTK 192
OTK 286	DAU1590738	OTK 286
OTK 310	DAU1590737	OTK 310
OTK 396	DAU1590740	OTK 396
1001	DAU1590820	External pipe
1002	DAU1590836	O Ring I 31.5X3.55
1003	DAU1590846	Guide casing
1004	DAU1590838	External pipe nut
1005	DAU1591114	WATER DISPENSER
1006	DAU1590354	Upper sprayer
1007	DAU1590816	Upper sprayer pipe
1009	DAU1590827	Upper sprayer holder block
1010	DAU1590853	Float holder
1011	DAU1590745	Screw ST2.9x22
1012	DAU1590854	FLOAT
1013	DAU1590395	Micro switch
1016	DAU1590387	Micro filter
1017	DAU1590839	Sump nut
1018	DAU1591073	Sump Gasket
1019	DAU1590803	SUMP
1022	DAU1590811	PVC hose
1027	DAU1590399	Drain Pump Without Casing
1036	DAU1590743	Clamp 14.5
1037	DAU1590871	Drain hose hook
1038	DAU1590835	Drain hose holder
1039	DAU1591038	Drain hose with small rubber elbow
1042	DAU1590872	Power cord
1043	DAU1591049	Inlet Valve
1045	DAU1591036	inlet hose assembly
1051	DAU1590841	Air breather nut
1053	DAU1590859	Air inlet
1064	DAU1590003	Lower sprayer assembly
1070	DAU1590398	Washing pump includes half load
1071+1072	DAU1590734	Motor support bracket

1073	DAU1590855	Motor insulation pan
1074	DAU1590817	Connect hose
1083	DAU1590187	Bend connect hose
1085	DAU1590828	HEATING ELEMENT SUPPORT
1086	DAU1591063	Heating elements
1088	DAU1590840	Water inlet nut
1089	DAU1590837	Water inlet gasket
1091	DAU1590389	Water inlet
1092	DAU1590393	Water inlet cover
1093	DAU1590879	Sensing Device
1096	DAU1590815	Inlet hose 1
1097	DAU1590812	Inlet hose 2
1098	DAU1590885	Flowmeter - A
1113	DAU1590388	plane filter
1114	DAU1590374	Scran collection
1115	DAU1591051	pressure switch 140/120
1116	DAU1590829	power supply loom clamping
1117	DAU1591109	PRESSURE SWITCH FOR HEATER
2002	DAU1590047	INNER DOOR
2004	DAU1590773	DISPENSER BRACKET
2005	DAU1590401	DISPENSER
2006	DAU1590873	Wiring harness
2008	DAU1590735	RING
2009	DAU1590018	LEFT HINGE
2010	DAU1590752	Joint pin
2011	DAU1590019	RIGHT HINGE
2012	DAU1590754	Door gemel assembly
2013	DAU1590732	Door spring
2014	DAU1590746	Door spring bolt
2017	DAU1590041	Outer door
2023	DAU1590383	HANDLE ASSY
2024	DAU1590876	Micro switch
2027	DAU1591050	Power switch
2033	DAU1590818	Indicator cover
2034	DAU1590404	CONTROL BOARD
2039	DAU1590392	Window
2044	DAU1590863	Power switch film
2058	DAU1590052	HANDLE

2059	DAU1590867	Window A
2060	DAU1590801	CONTROL PANEL
2070	DAU1590857	Circuit board box A
2071	DAU1590858	Circuit board box B
2950	DAU1590862	Power button
2951	DAU1590864	Program key
2954	DAU1590865	delay key
2957	DAU1590866	Half load key
3001	DAU1590033	Left side panel
3003	DAU1590785	Left uprights
3004	DAU1590051	Top assembly
3005	DAU1590868	Upper rear crosspiece
3006	DAU1590372	door clamp
3007	DAU1590755	Door lock
3009	DAU1590769	Upper front crosspiece
3010	DAU1591044	TANK GASKET
3011	DAU1590784	Right uprights
3012	DAU1590034	RIGHT PANEL
3013	DAU1590373	Upper basket cup holder
3014	DAU1590386	Cutlery basket assembly
3017	DAU1590016	LOWER BASKET
3018	DAU1591080	UPPER BASKET
3020	DAU1590367	Right washboard
3021	DAU1590380	Rail block
3022	DAU1591065	Rail
3023	DAU1591127	RAIL SUPPORT ASSY
3024	DAU1590822	Baseboard
3025	DAU1590368	Adjustable foot
3026	DAU1590005	Feet support assembly
3027	DAU1590771	Lower front crosspiece
3029	DAU1590783	Tray assembly
3030	DAU1590821	Left side baseboard
3032	DAU1590843	Tank band bracing block
3033	DAU1590766	Lower rear crosspiece
3034	DAU1590761	Middle rear crosspiece
3035	DAU1590851	Ration spoon
3050	DAU1590825	Top board hook