



























Position	Code	description
0= 00	630F612	Oven condensation kit
1= 1.2	032F2904D2	DOOR GLASS
2= 1.3	0313242TH	Inner glass
3= 1.4	063107	Hinge (male)
4= 1.5	51AF621SA	Left door trim
5= 1.6	51AF621DA	Right door trim
6= 1.7	037280061	Door handle
7= 1.8	053125	SEAL
8= 1.9	040056	Rubber
9= 1.10	51BF623A	Handle bar
10= 2.1	3316S410S	Cooktop
11= 2.2	3426640001	Manifold
12= 2.3	040041001	PLUG
13= 2.4	001130	SCREW
14= 2.7	51B6N01	Burners support
15= 2.8	027015	Inlet pipe plug
16= 2.9	053024.1	Sealing washer
17= 2.10	094254	CLAMP
18= 2.11	001227	SCREW
19= 2.13	103615	PIN
20= 2.14	035100	SPRING
21= 2.15	217530	Pan-support
22= 2.16	217303	Grate for small pans
23= 2.17	214062	NUT
24= 2.18	001234.1	Stainless steel screw V
25= 2.19	217498	Grid for woks
26= 3.1	35M6E003A	CONTROL PANEL
27= 3.2	51BF614S.1	Deflector
28= 3.3	040063	BUFFER
29= 3.4	0326E005	CONTROL PANEL GLASS
30= 3.5	1031579	Frontal trim
31= 4.8	450F61EM46	Oven cube
32= 4.10	094417DX	Rear hob support right
33= 4.11	094417SX	Rear hob support left
34= 4.13	51B6E02H	Right front trim
35= 4.14	51B6E03H	Left front trim
36= 4.15	103410080	SHIM

37= 4.16	214056	Shim nut
38= 4.17	36C6ED1S	Side panel right
39= 4.18	36C6ES1S	Side panel left
40= 4.19	094390	Door hinge (female)
41= 4.20	030191	Oven insulation
42= 4.23	411F607	Lower air conveyor
43= 4.24	421F602Z	Conveyor support
44= 4.25	411F605	Air conveyor
45= 4.26	079017	Tangential fan
46= 4.27	040056	Rubber
47= 4.30	68061008	Plinth
48= 4.34	053074	Upper seal
49= 4.35	053087	SEAL
50= 4.36	4116E01Z	REAR PANEL
51= 4.39	51B6E04Z	Lateral cross -piece support
53= 4.42	4216602Z	Bottom panel
54= 4.43	51BF603	Bottom element support
55= 4.44	51B6E06Z	Left rear trim
56= 4.45	51B6E05Z	Right rear trim
57= 4.46	037279080	Drawer handle front panel
58= 4.47	1031207	Lock pin
59= 4.48	094153	Anti tilt bracket
60= 4.49	4216E02Z	Drawer rear panel
61= 4.50	1031159	Drawer rail spacer
62= 4.51	1031160	Drawer spacer
63= 4.52	39E6E01L	Drawer front panel
64= 4.53	39K6E01Y	DRAWER
65= 4.54	421F603Z	REAR PANEL
66= 4.55	51B6107	Rail support
67= 4.56	030189	Rear insulation
68= 4.57	4216E01Z	Bottom rear panel
69= 4.58	103338DX/E	Right rail
70= 4.59	103338SX/E	Left rail
71= 4.60	103338DX/I	Right drawer rail
72= 4.61	103338SX/I	Right drawer rail
73= 6.1	2183009462	Burner knob
74= 6.4	106270GN	Tap diam 0.28 A
75= 6.4	106271	Tap diameter 0.33

76= 6.4	106273	Tap diameter 0.63 TR
77= 6.5	001282	Tap fixing screw
78= 6.6	094654	Tap bracket
79= 6.8A	215465	Burner-cupA
80= 6.8SR	215466	Burner-cupSR
81= 6.9SR	068110003	Burner-head Semi-rapid
82= 6.9A	068109003	Burner-head Auxiliary
83= 6.10A	216129005A	Burner-capA
84= 6.10SR	216130005A	Burner-capSR
85= 6.11	103468	Test point adaptor
86= 6.12	101182	Injector NATURAL GAS Ø 0.85 - A
87= 6.12	101335	Injector NATURAL GAS Ø 1.60 - TR
88= 6.12	101260	Injector NATURAL GAS Ø 1.12 - SR
89= 6.12	101233	Injector ULPG Ø 0.95 - TR
90= 6.12	101262	Injector ULPG Ø 0.53 - A
91= 6.12	101263	Injector ULPG Ø 0.70 - SR
92= 6.13	027013	NG connection
94= 6.15	215469	Burner-cup Triple-ring
95= 6.16	103347	Gas pressure regulator 1/2
96= 6.17	067026	Conical adaptor
97= 6.19	029666	Inlet pipe A
98= 6.20	029680	Inlet pipe left SR
99= 6.21	029679	Inlet pipe right SR
100= 6.22	029669	Inlet pipe TR
101= 6.24	107039	Burner thermocouple L=500 mm
102= 6.24	107044	Burner thermocouple L=250 mm - TR
103= 6.25	214057	NUT
104= 6.35	068112003	TR burner head
105= 6.36	216132005A	Burner-cap inside TR
106= 6.37	216133005A	Burner-cap outside TR
107= 6.38	053078	Triple-ring burner-cup gasket
108= 7.1	217646	Shelf support
109= 7.2	001142	Shelf support screw
110= 7.3	217558.2	WIRE SHELF
111= 7.5	217551.1	WIRE SHELF
112= 7.6	48BF602G	Oven tray
113= 7.13	217546	Grill-pan grid
114= 7.14	037144	Grill pan grid handle

115= 7.18	473070	Lateral catalytic panel
116= 8.1	2183009482	Oven knob
117= 8.15	050028.1	Oven switch
118= 8.16	066141	THERMOSTAT
119= 8.17	062089004	Top + grill element - 230 V
120= 8.18	062090004	Bottom element - 230 V
121= 8.22	062097004	Fan element
122= 8.23	47AF6020	Fan diffuser
123= 8.24	079008001F	Fan motor - 230 V
124= 8.27	213023	CLIP
125= 9.1	074105	Electronic timer
126= 11.1	072026	LAMP HOLDER
127= 11.2	073103	LAMP
128= 11.3	066219	oven safety temperature thermostat
129= 11.5	082082	Electronic ignition
130= 11.7	035094	Igniter spring
131= 11.8	084028	Spark plug L=250mm (auxiliary burner)
132= 11.8	084029	Spark plug L=630mm (semirapid &
133= 11.8	084033	Igniter TR - L = 500
134= 11.11	103230.1A	Terminal block protection
135= 11.13	041210	Earth plate
136= 11.14	052008	Cable clamp - rear cooker
137= 11.15	054041	CORD
138= 11.16	1131797	WIRING
139= 11.17	094221	Earth plate
140= 11.20	003077	RETAINING RING
141= 11.23	1031253	Ignition switches
142= 11.30	066080	Cut-off thermostat 55 degree
143= 11.32	051049	Terminal block 25A-3P
144= 11.33	073090	Control lamp cover (Blue)
145= 11.34	073091	Control lamp L = 230