




















Position	Code	description
0= 00a	6300050	Kit TCO 160 degree
0= 00b	6300055	Kit fan run on limiter
0= 00c	1031019	Silicon sleeve
0= 00d	6300021	Fan resistor kit
1= 1.1	103630063	Rear trim
2= 1.5	040041001	PLUG
3= 1.6	001007	Vis
4= 2.1	3429S50001	Manifold
5= 2.2	3319S502S	Cooktop
6= 2.5	51B9S01	Burners support
7= 2.6	027015	Inlet pipe plug
8= 2.12	053024.1	Sealing washer
9= 2.13	103615	PIN
10= 2.14	035100	SPRING
11= 2.15	217530	Pan-support
12= 2.16	217534	Central pan support
13= 2.17	214062	NUT
14= 2.18	094473	Fixing plate
15= 2.19	217303	Grate for small pans
16= 2.20	51B9S05	Cross-piece
17= 2.23	001234.1	Stainless steel screw V
18= 2.26	001167	SCREW
19= 2.27	217498	Grid for woks
20= 3.1	0329S003	CONTROL PANEL
21= 3.2	1031191	Control panel trim
22= 3.3	35M9S002A	Interior control panel
23= 3.8	213007	CLIP
24= 4.4	030267	Oven insulation
25= 4.5	030213	Rear insulation
26= 4.6	094417DX	Rear hob support right
27= 4.7	094417SX	Rear hob support left
28= 4.8	4119602	REAR PANEL
29= 4.9	4219S01Z	Upper shelter
30= 4.13	053101	SEAL
31= 4.18	1031295.1	SHIM L.150-180
32= 4.20	040061	BUFFER
33= 4.21	063075	HINGE

34= 4.23	371V9601L	FRONT PANEL
35= 4.24	373V9601A	Inside panel
36= 4.25	36C96D1S	Side panel right
37= 4.26	36C96S1S	Side panel left
38= 4.31	094412	BRACKET
39= 4.32	4219604Z	Rear insulation support
40= 4.33	4216108Z	Hinge protection
41= 4.35	103505A	Rotisserie motor support
42= 4.36	081084/NS	Left stopper
43= 4.37	081083/NS	Right stopper
44= 4.38	46A9S02Z	Air conveyor
45= 4.39	46A9S01Z	FUNNEL
46= 4.40	079025	Tangential fan
47= 4.42	040056	Rubber
48= 4.47	1031207	Lock pin
49= 4.48	094153	Anti tilt bracket
50= 4.50	45EN6106G	Oven side panel (Left)
51= 4.51	45E96001G	Top oven panel
52= 4.52	45EN6107G	Oven side panel (Right)
53= 4.53	45H96005G	BODY REAR PANEL
54= 4.55	45B3602G	Body front panel
55= 4.56	45K96004Z	Lower element cover
56= 4.57	211012	RIVET
57= 5.1	0329S004	DOOR GLASS
58= 5.2	037284009	HANDLE
59= 5.3	030187.1	Side door insulation
60= 5.4	51B9S12A	Trim handle
61= 5.5	001260	SCREW
62= 5.6	51A9S11DA	Right door trim
63= 5.7	51A9S11SA	Left door trim
64= 5.8	040051	Rubber
65= 5.9	0313111TH	Inner glass
66= 5.10	063146	Door hinge (male)
67= 5.11	063148	Door hinge (female)
68= 6.1	2183009462	Burner knob
69= 6.4a	106270GN	Tap diam 0.28 A
70= 6.4b	106271GN	Tap diam 0.33 SR
71= 6.4c	106272GN	Tap diam 0.43 R

72= 6.4d	106273GN	Tap diam 0.63
73= 6.5	001282	Tap fixing screw
74= 6.6	094654	Tap bracket
75= 6.8A	215465	Burner-cupA
76= 6.8SR	215466	Burner-cupSR
77= 6.8R	215467	Burner-cupTR
78= 6.9R	068111003	Burner-head Rapid
79= 6.9SR	068110003	Burner-head Semi-rapid
80= 6.9A	068109003	Burner-head Auxiliary
81= 6.10A	216129005A	Burner-capA
82= 6.10SR	216130005A	Burner-capSR
83= 6.10R	216131005A	Burner-cap R
84= 6.12a	101182	Injector NATURAL GAS Ø 0.85 - A
85= 6.12b	101273	Injector Rapid diam 1.45 - NG
86= 6.12c	101260	Injector NATURAL GAS Ø 1.12 - SR
87= 6.12d	101244	Injector Rapid diam 0.91 - LPG
88= 6.12e	101262	Injector ULPG Ø 0.53 - A
89= 6.12f	101263	Injector ULPG Ø 0.70 - SR
90= 6.14	053024.1	Sealing washer
91= 6.15	215469	Burner-cup Triple-ring
92= 6.16	103347	Gas pressure regulator 1/2
93= 6.17a	101335	Injector NATURAL GAS Ø 1.60 - TR
94= 6.17b	101233	Injector ULPG Ø 0.95 - TR
95= 6.19	029633	Inlet pipe - front right A
96= 6.20	029632	Inlet pipe - rear right SR
97= 6.21	029649	Inlet pipe - central TR
98= 6.22	029650	Inlet pipe - front left R
99= 6.23	029630	Inlet pipe - rear left SR
100= 6.25	068112003	TR burner head
101= 6.26a	107039	Burner thermocouple L=500 mm
102= 6.26b	107039	Burner thermocouple L=500 mm
103= 6.26c	107042	Burner thermocouple TR L=350 mm
104= 6.27	214057	NUT
105= 6.28	027013	NG connection
106= 6.29	067026	Conical adaptor
107= 6.30	103468	Test point adaptor
108= 6.36	216132005A	Burner-cap inside TR
109= 6.37	216133005A	Burner-cap outside TR

110= 6.38	053078	Triple-ring burner-cup gasket
111= 7.1	217291	Shelf support
112= 7.2	217497	Oven tray support
113= 7.3	48B8501G	Oven tray
114= 7.4	217626	OVEN SHELF
115= 7.6	47E9604G	Oven floor
116= 7.8	037208	Grill-pan grid handle
117= 7.9	217523	Grill-pan grid
118= 7.10a	080027	Rotisserie spear (without handle)
118= 7.10b	037012	Spear handle
119= 7.11	079014	Rotisserie motor
120= 7.12	217401.1	Rotisserie support
121= 7.14	473000	Catalytic panels
122= 7.15	1031584	Right telescopic runner
123= 7.16	1031585	Left telescopic runner
124= 8.1	2183009482	Oven knob
125= 8.2	214063	NUT
126= 8.3	103210.1	Oven switch support
127= 8.15	050028.1	Oven switch
128= 8.16	066072	Oven thermostat
129= 8.17	062100004	Top element
130= 8.18	062101004	Bottom element
131= 8.19	030076.1	Bottom element insulation
132= 8.20	4219602Z	Bottom insulation support
133= 8.21	4219605Z	Bottom element support
134= 8.22	103085	FILTER
135= 8.23	47A96010.2	Fan diffuser
136= 8.24	079008001F	Fan motor - 230 V
137= 8.26	062057004	Fan element - 230 V
138= 8.27	213025	CLIP
139= 9.1	074105	Electronic timer
140= 11.1	072023	Lamp holder assembly
141= 11.2	073103	LAMP
142= 11.3	051054	Terminal block
143= 11.4	103451	Terminal block cover
144= 11.5	6300088	KIT IGNITION COIL
145= 11.7a	035094	Igniter spring
146= 11.7b	084029	Spark plug L=630mm (semirapid & amp

147= 11.7c	084033	Igniter TR - L = 500
148= 11.8	084036	Igniter L = 900
149= 11.15	054094	Cord 3x2.5
150= 11.16	1132160	WIRING
151= 11.18	1031237	Ignition switches
152= 11.20	003077	RETAINING RING
153= 11.22	050058	Knob switch
154= 11.23	103210.1	Oven switch support
155= 11.24	214063	NUT
157= 11.33	073092	Control lamp cover
158= 11.34	073091	Control lamp L = 230
159= 11.36	066190	CUT-OFF THERMOSTAT