




Position	Code	description
1= 1.1	336D041SD2	Hob top
2= 1.2	4116D03	Burner casing
3= 1.3	053065	SEAL
4= 1.5	001221	SCREW
5= 1.7	094338	Fixing bracket
6= 1.11	094345	BRACKET
7= 1.12	094346	Terminal block protection
8= 1.16	10348100X	PLUG
9= 1.22	58B6303	Bar
10= 4.1	2183009463	KNOB
11= 4.2	050033	Normal/rapid electric plate switch
12= 4.3a	04725230	Normal electric plate diam 145 - 1000 W- 230 V
13= 4.3b	04726230	Normal electric plate diam 180 - 1500 W - 230 V
14= 4.4a	103084R	Normal/rapid plate protection diam 145
15= 4.4b	103081R	Normal/rapid plate protection diam 180
16= 4.6	053055	Switch gasket
17= 4.8	214055	NUT
18= 4.11a	04727230	Rapid electric plate diam 145 - 1500 W - 230 V
19= 4.11b	04763230	Rapid electric plate diam 180 - 2000 W - 230 V
20= 5.1	1131062	WIRING
21= 5.2	051055	Terminal block
22= 5.3	073058	Control lamp L 230
23= 5.4	073057	Control lamp cover