


DEWC155D



Position	Code	description
000A	EI1271	Box for power board assembly (box only without pcb)
000B	EI1277	FIVE SIDED KEYS
a	EI1036	Thermistor (air sensor)
b	EI1205	Bottom grill
1	EI1082	Top cover part
2	EI1001	Left door upper hinge
5	EI1003	Right door upper hinge
6	EI1098	Door hinge centre
7	EI1005	Rail (18inch)
8	EI1006	Shelf
10	EI1099	Upper windway plate
11	EI1052	LAMP COVER
12	EI1049	Electrical box cover
13	EI1068	Led Lamp
15	EI1012	TRANSFORMER
16	EI1015	Fan net
17a	EI1065	Fan (see technical info.)
17b	EI1028	Fan motor 12V (new version)
18	EI1100	Windway plate
19	EI1047	Thermistor (defrost sensor)
20	EI1047	Thermistor (defrost sensor)
21	EI1017	Evaporator foam
22	EI1035	Thermistor cover
23	EI1018	EVAPORATOR
24	EI1019	Assembly pipe
26	EI1021	Drier
27	EI1022	Condenser
28	EI1023	COMPRESSOR
30	EI1024	JUNCTION BOX
31	EI1025	Power line
32	EI1026	Terminal Plate
33	EI1027	Compressor support plate
34	EI1014	Fan for evaporator
35	EI1029	Fan Bracket Outside
36	EI1030	Compressor connecting pipe
37	EI1031	Water drip tray
38	EI1032	Feet

39	EI1204	SUPP BRACKET OF FRONT LEGS
40	EI1205	Bottom grill
41	EI1101	Fan heating foam
42	EI1102	Drainage pipe
43	EI1093	Water tray
44	EI1090	HEATER
45	EI1091	Heater Insulation Board
46	EI1092	Heater Fan
47	EI1094	Heater Fan Mesh
48	EI1103	Lower windway plate
49	EI1104	Mid windway plate foam
50	EI1038	12 inch roller
51	EI1039	Shelf WE2
53	EI1037	WB support
54	EI1040	DOOR
55	EI1041	Right lower hinge
56	EI1042	Door hinge centre
57	EI1043	Keylock
58	EI1044	Left lower door hinge
59	EI1045	HANDLE
314A	EI1140	PCB board plus Displays if on the board label is written DG3-1033.1
314B	EI1145	PCB board plus Displays if on the board label is written DG3-1050.1