


DEWC166S



Position	Code	description
0	EI1277	FIVE SIDED KEYS
0a	EI1271	Box for power board assembly (box only without pcb)
0b	EI1262	Air-circulating pipe
1	EI1000	Front Insert
2	EI1001	Left door upper hinge
4	EI1003	Right door upper hinge
5	EI1004	Door hinge centre
6	EI1005	Rail (18inch)
7	EI1006	Shelf
8	EI1007	Upper windway plate strip
9	EI1008	LED light
10	EI1009	Upper windway foam 5
11	EI1276	Control kit: PCB plus Display (DG3-1029.2.2)
12	EI1011	Heat release plate
13	EI1012	TRANSFORMER
14	EI1013	Upper windway foam 4
15a	EI1065	Fan (see technical info.)
15b	EI1028	Fan motor 12V (new version)
16	EI1015	Fan net
17	EI1275	Air duct board A
18	EI1017	Evaporator foam
19	EI1018	EVAPORATOR
20	EI1019	Assembly pipe
21	EI1047	Thermistor (defrost sensor)
23	EI1021	Drier
24	EI1022	Condenser
25	EI1023	COMPRESSOR
26	EI1025	Power line
27	EI1026	Terminal Plate
30	EI1027	Compressor support plate
31	EI1014	Fan for evaporator
32	EI1029	Fan Bracket Outside
33	EI1030	Compressor connecting pipe
34	EI1031	Water drip tray
36	EI1032	Feet
37	EI1204	SUPP BRACKET OF FRONT LEGS
38	EI1205	Bottom grill

40	EI1035	Thermistor cover
41	EI1036	Thermistor (air sensor)
41b	EI1047	Thermistor (defrost sensor)
42	EI1037	WB support
43	EI1038	12 inch roller
44	EI1039	Shelf WE2
46	EI1040	DOOR
47	EI1041	Right lower hinge
48	EI1042	Door hinge centre
49	EI1043	Keylock
50	EI1044	Left lower door hinge
51	EI1045	HANDLE