




Position	Code	description
01	3370501SDL	Hob top
02	4117001	Burner casing
03	053065	SEAL
04	094335	Fixing bracket
05	001221	SCREW
06	094338	Fixing bracket
07	217561	Right top grate
08	217563	Central top grate
09	217562	Left top grate
10	029705	SR - Front right burner pipe
11	029708	R - burner pipe
12	029707	TC - burner pipe
13	029706	SR - Rear left burner pipe
14	029704	A - burner pipe
15	067026	Conical adaptor
16a	106224	Tap - diameter 0.25 - A
16b	106230	SR tap - diameter 0.30
16c	106231	R tap - diameter 0.40
16d	106232	Tap - diameter 0.62
17	001189	SCREW
18	094304	Tap bracket
19	217303	Grate for small pans
20	040070	Rear fixing bar
21	040057	Rubber joint
22	3427050G01	5 gas inlet pipe
23	067008	Elbow
24	053024.1	Sealing washer
25a	215465	Burner-cupA
25b	215466	Burner-cupSR
25c	215467	Burner-cupTR
26a	101182	Injector NATURAL GAS Ø 0.85 - A
26b	101260	Injector NATURAL GAS Ø 1.12 - SR
26c	101273	Injector Rapid diam 1.45 - NG
26d	101261	Injector - diameter 1.65 TR - Natural gas
26e	101262	Injector ULPG Ø 0.53 - A
26f	101263	Injector ULPG Ø 0.70 - SR
26g	101244	Injector Rapid diam 0.91 - LPG

26h	101233	Injector ULPG Ø 0.95 - TR
27a	068109003	Burner-head Auxiliary
27b	068110003	Burner-head Semi-rapid
27c	068111003	Burner-head Rapid
28a	216129005A	Burner-capA
28b	216130005A	Burner-capSR
28c	216131005A	Burner-cap R
29	215469	Burner-cup Triple-ring
30	053078	Triple-ring burner-cup gasket
31	068115003	Burner-head Triple-ring
32	216133005A	Burner-cap outside TR
33	216132005A	Burner-cap inside TR
35a	084028	Spark plug L=250mm (auxiliary burner)
35b	084029	Spark plug L=630mm (semirapid &
35c	084032	Spark plug L=250mm (triple-ring burner)
36	035094	Igniter spring
37	082095	Electronic Ignition
38	051054	Terminal block
40	054090	Power cord with plug 3 x 0.75 mm ²
41	103359	Ignition switches
42	003023	Snap ring
43	003055	WASHER
44	035095	SPRING
45	094337	Inlet pipe fixing bracket
46	103360	Ignition earth cable - L150
47	103595	Red cable L400
48	103594	Yellow-Green cable L 400 mm
50	2183007363	KNOB
51	10348100X	PLUG
52	217498	Grid for woks
53a	107039	Burner thermocouple L=500 mm
53b	107039	Burner thermocouple L=500 mm
53c	107044	Burner thermocouple L=250 mm - TR
54	214057	NUT
55	094295	Spacing
56	103468	Test point adaptor
57	103347	Gas pressure regulator 1/2