











Position	Code	description
1= 1.1	332I8508S	Hob top
2= 1.2	0752176A	CONTROL PANEL
3= 1.3	069047080	Plate left - (Black)
4= 1.4	001126	Screw (Black)
5= 1.6	069048080	Plate right - (Black)
6= 1.7	217501	Top grate
7= 1.9	4118606	Burner casing
8= 1.10	053038	SEAL
9= 1.11	094154	Fixing bracket
10= 1.12	001130	SCREW
11= 1.13	217504	Central grate
12= 1.14	215443	Fish burner
13= 1.15	215191	A burner
14= 1.16	215205	SR burner
15= 1.17	215204	R burner
16= 1.18	215190	UR burner
17= 1.21	217498	Grid for woks
18= 1.22	094283	Fixing bracket 3gas
19= 1.23	094284	Fixing bracket 2gas
20= 1.25	103118002	Plug (Black)
21= 1.29	217303	Grate for small pans
22= 1.30	001024	SCREW
23= 1.31	085037	Spacing bolt H 32.5 mm
24= 1.32	001047	SCREW
25= 1.33	094150	Right bracket
26= 1.34	094148	Left bracket
27= 1.35	003034	WASHER
28= 1.36	001089	SCREW
29= 1.37	094295	Spacing
30= 1.38	085062	Double burner sleeve
31= 1.39	094285	UR burner thermocouple bracket
32= 1.40	094286	R - burner thermocouple bracket
33= 1.41	094288	Fish burner thermocouple bracket
34= 1.42	094093	A - SR burner thermocouple bracket
35= 2.2a	106097	Tap - diameter 0.27 SR
36= 2.2b	106047	Tap - diameter 0.35 R
37= 2.2c	106164	Tap - diameter 0.43 UR

38= 2.3a	101075	Injector - diameter 0.47
39= 2.3b	101119	Injector - diameter 0.60
40= 2.3c	101082	Injector - diameter 0.76
41= 2.3d	101089	Injector - diameter 0.90
42= 2.3e	101066	Injector - diameter 0.70
43= 2.3f	101129	Injector - diameter 1.15
44= 2.3g	101167	Injector - diameter 1.45
45= 2.4	3428350G01	5 gas inlet pipe
46= 2.5	094088004	Tap bracket (4 gas)
47= 2.6	001060	SCREW
48= 2.7	094085	Inlet pipe fixing bracket
49= 2.8	053024.1	Sealing washer
50= 2.9	067008	Elbow
51= 2.12	067026	Conical adaptor
52= 2.15a	107029	Burner thermocouple (L=850 mm)
53= 2.15b	107030	Burner thermocouple (L=400 mm)
54= 2.16	R00550280	BRASS NUT FOR THERMOCOUPLE
55= 2.17	2183382S96	Knob
56= 2.20	103347	Gas pressure regulator 1/2
57= 3.1a	068060006	Burner-head A
58= 3.1b	068061006	Burner-head SR
59= 3.1c	068062006	Burner-head R
60= 3.2a	216005311	Burner-cap ring A (Black)
61= 3.2b	216006325	Burner-cap ring SR (Black)
62= 3.2c	216007325	Burner-cap ring R (Black)
63= 3.3a	216078005	Burner-cap A
64= 3.3b	216079005	Burner-cap SR
65= 3.3c	216089508	SPART.R 24FORI D3 GH.GRIG
66= 3.4	068075006	Double ring burner-head
67= 3.5	216100140	DR outside burner-ring
68= 3.6	216074230	BURNER CAP RING
69= 3.7	216070080	Double ring burner-cap (Black)
70= 3.8	216116005	Fish burner-cap
71= 3.9	068100005	Fish burner
72= 5.1	051036	Terminal block 16A-2P PA 44-2FV
73= 5.2	052001	Wire fastener
74= 5.5	054055	Cord with plug 3x0.75
75= 5.6a	084007	Spark plug - 400 mm

77= 5.6c	084014	Spark plug - 1050 mm
79= 5.7	035033	Spark plug spring
80= 5.9a	081033	Ignition push-button (White)
81= 5.9b	081032	Ignition push-button (Black)
82= 5.19	077026	Ignition switch
83= 5.14	003023	Snap ring
84= 5.20	082095	Electronic Ignition