




Position	Code	description
0a	040060	Rubber plug for trivets
01	3390502SDA	Hob top
02	4119001	Burner casing
03	053038	SEAL
04	094154	Fixing bracket
05	001130	SCREW
06	217505	Central grate
07	217501	Top grate
08	040068	Rear fixing bar
09	040049	SPACER
10	029734	Left SR burner pipe
11	029681	A - burner pipe
12	029731	R - burner pipe
13	029735	Right SR burner pipe
14	029733	Central TR burner pipe
15	067026	Conical adaptor
16a	106207	Tap - diameter 0.27
16b	106208	Tap - diameter 0.34
16c	106209	Tap - diameter 0.44
16d	106221	Tap - diameter 0.65
17	001202	SCREW
18	094315	Tap bracket
19	040057	Rubber joint
21	040064	STOPPER
22	3428650G01	5 gas inlet pipe
23	067008	Elbow
24	053024.1	Sealing washer
25a	215465	Burner-cupA
25b	215466	Burner-cupSR
25c	215467	Burner-cupTR
26a	101182	Injector NATURAL GAS Ø 0.85 - A
26b	101260	Injector NATURAL GAS Ø 1.12 - SR
26c	101273	Injector Rapid diam 1.45 - NG
26d	101261	Injector - diameter 1.65 TR - Natural gas
26e	101262	Injector ULPG Ø 0.53 - A
26f	101263	Injector ULPG Ø 0.70 - SR
26g	101244	Injector Rapid diam 0.91 - LPG

26h	101233	Injector ULPG Ø 0.95 - TR
27a	068109001	Burner-head A
27b	068110001	Burner-head SR
27c	068111001	Burner head A
28a	216129005A	Burner-capA
28b	216130005A	Burner-capSR
28c	216131005A	Burner-cap R
29	215469	Burner-cup Triple-ring
30	053078	Triple-ring burner-cup gasket
31	068115001	Burner-head TR
32	216133005A	Burner-cap outside TR
33	216132005A	Burner-cap inside TR
34	094085	Inlet pipe fixing bracket
35a	084028	Spark plug L=250mm (auxiliary burner)
35b	084029	Spark plug L=630mm (semirapid & amp
35c	084032	Spark plug L=250mm (triple-ring burner)
36	035094	Igniter spring
37	082095	Electronic Ignition
38	051054	Terminal block
39	103451	Terminal block cover
40	054090	Power cord with plug 3 x 0.75 mm ²
41	103749	Ignition switches
42	003039	RETAINING RING
46	103360	Ignition earth cable - L150
47	103741	Red cable L=950mm
48	103742	Yellow-Green cable - L 400 mm
50	2183007363	KNOB
51	10348100X	PLUG
52	217303	Grate for small pans
53	217498	Grid for woks
55	094295	Spacing
56	103468	Test point adaptor
57	103347	Gas pressure regulator 1/2