




Position	Code	description
0a	040060	Rubber plug for trivets
01	3390503SDA	Hob top
02	4119001	Burner casing
03	053038	SEAL
04	094154	Fixing bracket
05	001130	SCREW
06	217504	Central grate
07	217501	Top grate
08	040068	Rear fixing bar
09	040049	SPACER
10	029745	Left SR burner pipe
11	029747	A - burner pipe
12	029748	TC - burner pipe
13	029698	Right SR burner pipe
14	029749	Central fish-burner pipe
15	067026	Conical adaptor
16a	106224	Tap - diameter 0.25 - A
16b	106230	SR tap - diameter 0.30
16c	106232	Tap - diameter 0.62
17	001189	SCREW
18	094304	Tap bracket
19	217303	Grate for small pans
20a	107039	Burner thermocouple L=500 mm
20b	107039	Burner thermocouple L=500 mm
20c	107052	Burner thermocouple L=850mm (left burners)
20d	107053	TC Burner thermocouple - 850 mm
21	214057	NUT
22	3428650G01	5 gas inlet pipe
23	067008	Elbow
24	053024.1	Sealing washer
25a	215465	Burner-cupA
25b	215466	Burner-cupSR
26a	101182	Injector NATURAL GAS Ø 0.85 - A
26b	101260	Injector NATURAL GAS Ø 1.12 - SR
26c	101273	Injector Rapid diam 1.45 - NG
26d	101261	Injector - diameter 1.65 TR - Natural gas
26e	101262	Injector ULPG Ø 0.53 - A

26f	101263	Injector ULPG Ø 0.70 - SR
26g	101244	Injector Rapid diam 0.91 - LPG
26h	101233	Injector ULPG Ø 0.95 - TR
27a	068109003	Burner-head Auxiliary
27b	068110003	Burner-head Semi-rapid
28a	216129005A	Burner-capA
28b	216130005A	Burner-capSR
29	215469	Burner-cup Triple-ring
30	053078	Triple-ring burner-cup gasket
31	068115003	Burner-head Triple-ring
32	216133005A	Burner-cap outside TR
33	216132005A	Burner-cap inside TR
34	094085	Inlet pipe fixing bracket
35a	084028	Spark plug L=250mm (auxiliary burner)
35b	084029	Spark plug L=630mm (semirapid &
35c	084033	Igniter TR - L = 500
36	035094	Igniter spring
37	082095	Electronic Ignition
38	051054	Terminal block
39	103451	Terminal block cover
40	054090	Power cord with plug 3 x 0.75 mm ²
41	103741	Red cable L=950mm
42	103742	Yellow-Green cable - L 400 mm
43	103360	Ignition earth cable - L150
45	103359	Ignition switches
46	003055	WASHER
47	003023	Snap ring
48	035095	SPRING
50	2183007363	KNOB
51	10348100X	PLUG
52	040057	Rubber joint
53	217498	Grid for woks
55	094295	Spacing
56	103468	Test point adaptor
57	103347	Gas pressure regulator 1/2
59	0681140035	Fish-burner
60	001212	SCREW
61	215471	Burner-cup (fish)