





| Position | Code      | description                    |
|----------|-----------|--------------------------------|
| 0        | BF72X2667 | PROG. CARD MOUNTING            |
| 100      | BF72X5356 | CERAMIC HOB                    |
| 102      | BF75X5552 | GASKET                         |
| 104      | BF72X5763 | EQUIPMENT SUPPORT              |
| 116      | BF72X7538 | KEYBOARD CARD                  |
| 130      | BF79X8658 | SEAL                           |
| 145      | BF72X3360 | GROMMET                        |
| 150      | BF72X4486 | CABLE 380 MM                   |
| 155      | BF77X8699 | SEAL PLUG                      |
| 156      | BF77X2732 | WALLET OF SCREWS               |
| 159      | BF77X3740 | SPRING                         |
| 160      | BF72X5380 | INDUCTOR D160 2200W            |
| 162      | BF72X6006 | DISC 160MM                     |
| 163      | BF72X5997 | TEMPERATURE SENSOR 250MM-2P    |
| 173      | BF72X6813 | POWER CARD                     |
| 200      | BF72X4243 | RADIANT ELEMENT 1500W D180     |
| 201      | BF72X0823 | RADIANT ELEMENT 1700 750W D230 |
| 227      | BF77X2810 | SPRING                         |
| 228      | BF77X3557 | PLATE                          |
| 260      | BF72X0979 | RELAY BOARD                    |
| 261      | BF72X5381 | INDUCTOR D 210                 |
| 262      | BF72X6005 | DISC 230MM                     |
| 263      | BF72X5998 | TEMPERATURE SENSOR 250MM-3P    |