




| Position | Code       | description                 |
|----------|------------|-----------------------------|
| 000A     | BF72X2667  | PROG. CARD MOUNTING         |
| 000B     | BF77X2732  | WALLET OF SCREWS            |
| 100      | BF72X5338  | BLACK CERAMIC HOB           |
| 102      | BF75X5552  | GASKET                      |
| 104      | BF72X5763  | EQUIPMENT SUPPORT           |
| 116      | BF72X7788  | POWER CARD                  |
| 117      | BF72X7789  | KEYBOARD CARD               |
| 118      | BF70X0002  | RELAY BOARD                 |
| 125      | BF76X5411  | CLIPS                       |
| 150      | BF70X0790  | INDUCTOR 210MM              |
| 152      | BF72X6005  | DISC 230MM                  |
| 153      | BF72X5997  | TEMPERATURE SENSOR 250MM-2P |
| 155      | BF72X5998  | TEMPERATURE SENSOR 250MM-3P |
| 158      | BF77X8699  | SEAL PLUG                   |
| 159      | BF77X3740  | SPRING                      |
| 162      | BF71X4404  | DISC                        |
| 170      | BF71X3472  | INDUCTOR D 160              |
| 172      | BF72X6006  | DISC 160MM                  |
| 196      | BF72X9110  | FAN                         |
| 198      | BFAS004879 | POWER CARD 3600W            |