




| Position | Code       | description                           |
|----------|------------|---------------------------------------|
| 0        | 103495     | Red cable L200                        |
| 1        | 333A20ESDA | Cooktop                               |
| 2        | 2183007363 | KNOB                                  |
| 3        | 040057     | Rubber joint                          |
| 7a       | 068111003  | Burner-head Rapid                     |
| 7b       | 068110003  | Burner-head Semi-rapid                |
| 9a       | 216131005A | Burner-cap R                          |
| 9b       | 216130005A | Burner-capSR                          |
| 11       | 4113A13    | CASING                                |
| 12       | 054090     | Power cord with plug 3 x 0.75 mm2     |
| 13       | 051054     | Terminal block                        |
| 14       | 10348100X  | PLUG                                  |
| 15       | 094271     | BRACKET                               |
| 16       | 217303     | Grate for small pans                  |
| 17       | 053037     | SEAL                                  |
| 20       | 067008     | Elbow                                 |
| 21       | 053024.1   | Sealing washer                        |
| 23       | 082076     | Electronic ignition                   |
| 25       | 103451     | Terminal block cover                  |
| 26       | 3423A20G07 | Inlet pipe                            |
| 29       | 001221     | SCREW                                 |
| 30       | 094338     | Fixing bracket                        |
| 33       | 035094     | Igniter spring                        |
| 35       | 084028     | Spark plug L=250mm (auxiliary burner) |
| 36       | 217515005  | Pan-support                           |
| 38       | 106231     | R tap - diameter 0.40                 |
| 39       | 106230     | SR tap - diameter 0.30                |
| 40       | 029595     | R gas pipe                            |
| 41       | 029594     | SR gas pipe                           |
| 42a      | 101273     | Injector Rapid diam 1.45 - NG         |
| 42b      | 101244     | Injector Rapid diam 0.91 - LPG        |
| 42c      | 101260     | Injector NATURAL GAS Ø 1.12 - SR      |
| 42d      | 101263     | Injector ULPG Ø 0.70 - SR             |
| 43a      | 215467     | Burner-cupTR                          |
| 43b      | 215466     | Burner-cupSR                          |
| 44       | 067026     | Conical adaptor                       |
| 45       | 214057     | NUT                                   |

|    |        |                              |
|----|--------|------------------------------|
| 46 | 107039 | Burner thermocouple L=500 mm |
| 47 | 107039 | Burner thermocouple L=500 mm |
| 48 | 035095 | SPRING                       |
| 49 | 003055 | WASHER                       |
| 50 | 103494 | Ignition microswitches       |
| 51 | 103347 | Gas pressure regulator 1/2   |
| 52 | 103468 | Test point adaptor           |