




Position	Code	description
01	103595	Red cable L400
1	333A108SDA	Cooktop
02	103607	Cable L = 400
2	2183007363	KNOB
3	040057	Rubber joint
4	094295	Spacing
5	068112003	TR burner head
6	216133005A	Burner-cap outside TR
7	216132005A	Burner-cap inside TR
9	217516005	Pan-support
10a	101261	Injector - diameter 1.65 TR - Natural gas
10b	101233	Injector ULPG Ø 0.95 - TR
11	4113A13	CASING
12	054090	Power cord with plug 3 x 0.75 mm ²
13	051054	Terminal block
14	10348100X	PLUG
15	094271	BRACKET
16	214057	NUT
17	053037	SEAL
18	029597	DR pipe
19	215469	Burner-cup Triple-ring
20	067008	Elbow
21	053024.1	Sealing washer
22	094243	Ignition coil bracket
23	082076	Electronic ignition
24	107044	Burner thermocouple L=250 mm - TR
25	103451	Terminal block cover
26	3423A10G04	Inlet pipe
27	053078	Triple-ring burner-cup gasket
29	001221	SCREW
30	094338	Fixing bracket
31	094360	Fixing bracket
34	035094	Igniter spring
35	084032	Spark plug L=250mm (triple-ring burner)
37	001234.1	Stainless steel screw V
38	106232	Tap - diameter 0.62
40	217507	Wok pan support

44	067026	Conical adaptor
45	51B3A03	Burners support
47	003055	WASHER
48	035095	SPRING
49	003023	Snap ring
50	103593	Ignition microswitch
51	103347	Gas pressure regulator 1/2
52	103468	Test point adaptor