




2002

2036

2027

2950

2028

2024

2023

2957

2954

2951

2952

2039

2001

2003

2004

2005

2007

2008

2009

2010

2011

2018

2017


2014


2013

2012

2034

2033





Position	Code	description
C1060	DAU1590255	Water inlet nut
C5004	DAU1590409	rinsing agent cup
OTK 175	DAU1590064	OTK 175
OTK 396	DAU1590066	OTK 396
OTK 440	DAU1590063	OTK 440
1001	DAU1590179	External pipe
1002	DAU1590242	O Ring I 31.5X3.55
1003	DAU1590267	Guide casing
1004	DAU1590838	External pipe nut
1005	DAU1590272	Water dispenser
1006	DAU1590520	Upper sprayer
1007	DAU1591058	Upper spray pipe
1008	DAU1590257	Ring nut gasket for upper sprayer
1009	DAU1590222	Upper sprayer holder block
1010	DAU1590280	Float support
1011	DAU1590075	Screw ST2.9x22
1012	DAU1590281	FLOAT
1013	DAU1590313	Micro switch
1015	DAU1591061	Central filter assembly
1016	DAU1590286	Micro filter
1017	DAU1590253	Sump nut
1018	DAU1590248	Sump gasket
1019	DAU1590154	SUMP
1022	DAU1590192	PVC hose
1024	DAU1590190	Connect duct of drain pipe
1027+1028	DAU1591053	Drain pump
1036	DAU1590067	Clamp 14.9
1037	DAU1590408	Drain hose hook
1038	DAU1590241	Drain hose holder
1039	DAU1591037	Drain hose
1040	DAU1591124	ANTI-DISTURBANCE CONTROL
1041	DAU1590346	Connection box
1042	DAU1590304	Power cord
1043	DAU1590311	Inlet valve
1045	DAU1590188	Inlet hose assembly
1051	DAU1590252	Ring nut air breather
1053	DAU1590287	Air inlet

1064	DAU1590061	Lower sprayer
1065	DAU1590256	Lower sprayer nut
1066	DAU1590143	Lower sprayer axes
1067	DAU1590218	Outer tie-in
1068	DAU1590244	Inner tie-in O ring
1069	DAU1590217	Inner tie-in
1070	DAU1590398	Washing pump includes half load
1071	DAU1591048	Motor vibration-proof pad
1072	DAU1590734	Motor support bracket
1073	DAU1590283	Motor insulation pan
1074	DAU1591070	Connect Hose
1083	DAU1590187	Bend connect hose
1085	DAU1590236	HEATING ELEMENT SUPPORT
1086	DAU1591063	Heating elements
1088	DAU1590411	Water inlet cover
1089	DAU1590249	Water inlet gasket
1091	DAU1590288	Water inlet
1092	DAU1590410	water inlet cover
1093	DAU1591089	Sensing device
1096	DAU1590197	Inlet hose 1
1097	DAU1590198	Inlet hose 2
1098a	DAU1590885	Flowmeter - A
1098c	DAU1590886	NEW flowmeter connector
1117	DAU1591052	Pressure Switch Assy
2001	DAU1590275	Door edge guard piece
2002	DAU1591035	INNER DOOR
2003	DAU1591086	Inner door gasket
2004	DAU1590116	Dispenser bracket
2005	DAU1590401	DISPENSER
2006	DAU1590307	Wiring harness
2007	DAU1590347	Inner door foam
2008	DAU1590060	RING
2009	DAU1590088	LEFT HINGE
2010	DAU1590082	Joint pin
2011	DAU1590089	RIGHT HINGE
2012	DAU1590085	DOOR HINGE
2013	DAU1590728	Door spring
2014	DAU1590077	Door spring bolt

2015	DAU1590074	Screw M5 X 10
2016	DAU1590076	Nut M5
2017	DAU1590122	Outer door
2018	DAU1591056	CONTROL PANEL
2023	DAU1590383	HANDLE ASSY
2024	DAU1590315	Door switch
2027	DAU1591050	Power switch
2028	DAU1590326	Red pilot lamp
2033	DAU1590177	Indicator cover
2034	DAU1591118	CONTROL BOARD
2036	DAU1590282	CONTROL BOARD BOX
2039	DAU1590295	Window
2950	DAU1591057	POWER BUTTON
2951	DAU1590171	Program key
2952	DAU1590172	Start/Pause key
2954	DAU1590173	Delay key
2957	DAU1590174	Half load key
3001	DAU1590108	Left side panel
3002	DAU1590140	Back cover board
3003	DAU1590413	Left frame
3004	DAU1590142	Ceiling board
3005	DAU1590094	Upper rear crosspiece
3006	DAU1590225	Coupling block
3007	DAU1590090	Door lock hook
3008	DAU1590219	Top board hook
3009	DAU1590095	Upper front crosspiece
3010	DAU1591044	TANK GASKET
3011	DAU1590414	RIGHT FRAME
3012	DAU1590028	Right side panel
3013	DAU1590224	Cup rack
3014	DAU1591047	Cutlery basket assembly
3017	DAU1590014	LOWER BASKET
3018	DAU1590560	Upper basket (includes wheels)
3019	DAU1590348	Ceiling/side sound-proof felt
3020	DAU1590212	Right side baseboard
3021	DAU1591041	Guide rail block
3022a	DAU1590118	V-shape basket guide
3022b	DAU1590117	Guide rail

3023a	DAU1591127	RAIL SUPPORT ASSY
3023b	DAU1591128	GUIDE RAIL BRACKET FLAT
3024	DAU1590210	Baseboard
3025	DAU1590368	Adjustable foot
3026	DAU1590056	Foot rest
3027	DAU1590092	Lower front crosspiece
3028	DAU1590185	Float hose
3029	DAU1590412	Tray assembly
3030	DAU1590211	Left side baseboard
3031	DAU1590126	Tank assembly
3032	DAU1590260	Tank band bracing block
3033	DAU1590097	Lower rear crosspiece
3034	DAU1590093	Middle rear crosspiece
3035	DAU1590276	Measurable spoon
3036	DAU1590232	Left claw
3037	DAU1590231	Right claw
3038	DAU1590235	Framework support
3039	DAU1590081	Orientation pole
3040	DAU1590266	Adjustable basket handle
3041	DAU1590073	Slip bracket
3042+3043	DAU1591071	Basket wheel + wheel shaft