













Position	Code	description
C5004	DAU1590409	rinsing agent cup
OTK175	DAU1590064	OTK 175
OTK396	DAU1590066	OTK 396
OTK440	DAU1590063	OTK 440
1000a	DAU1590415	Brackets and screws for door installation (DW97DOORKIT)
1000b	DAU1590886	NEW flowmeter connector
1000c	DAU1590609	Silver kick plate
1000d	DAU1590885	Flowmeter - A
1001	DAU1591113	EXTERNAL PIPE
1002	DAU1590242	O Ring I 31.5X3.55
1003	DAU1590267	Guide casing
1004	DAU1590838	External pipe nut
1005	DAU1590272	Water dispenser
1006	DAU1590520	Upper sprayer
1007	DAU1590195	Upper sprayer pipe
1008	DAU1590257	Ring nut gasket for upper sprayer
1009	DAU1590222	Upper sprayer holder block
1010	DAU1590280	Float support
1011	DAU1590075	Screw ST2.9x22
1012	DAU1590281	FLOAT
1013	DAU1590395	Micro switch
1015	DAU1591061	Central filter assembly
1016	DAU1590286	Micro filter
1017	DAU1590253	Sump nut
1018	DAU1590248	Sump gasket
1019	DAU1590155	SUMP
1020	DAU1590787	Clamp 12.9
1022	DAU1590189	PVC hose
1024	DAU1590201	Connect duct of drain pipe
1027+28	DAU1591053	Drain pump
1029	DAU1590277	Salt filler
1030	DAU1590294	Softener cover assembly
1031	DAU1590794	Softener cover gasket
1032	DAU1590251	Softener nut
1034	DAU1590800	Softener
1035	DAU1591121	FLEXIBLE HOSE

1036	DAU1590067	Clamp 14.9
1037	DAU1590408	Drain hose hook
1038	DAU1590241	Drain hose holder
1039	DAU1591037	Drain hose
1040	DAU1590341	Anti-disturbance controller
1042	DAU1590306	Power cord
1043	DAU1590311	Inlet valve
1045	DAU1591036	inlet hose assembly
1046	DAU1590183	Regeneration hose
1047	DAU1590182	Outlet hose of air breather
1048	DAU1590181	Inlet hose of air breather
1051	DAU1590252	Ring nut air breather
1053	DAU1590287	Air inlet
1054	DAU1591116	AIR BREATHER ASSY
1064	DAU1590061	Lower sprayer
1065	DAU1590256	Lower sprayer nut
1066	DAU1590143	Lower sprayer axes
1067	DAU1590218	Outer tie-in
1068	DAU1590244	Inner tie-in O ring
1069	DAU1590217	Inner tie-in
1070	DAU1590398	Washing pump includes half load
1071+72	DAU1590058	Motor support bracket
1073	DAU1590284	Motor insulation pan
1074	DAU1590817	Connect hose
1083	DAU1590187	Bend connect hose
1085	DAU1590236	HEATING ELEMENT SUPPORT
1086	DAU1591063	Heating elements
1088	DAU1590255	Water inlet nut
1089	DAU1590249	Water inlet gasket
1091	DAU1590289	Water inlet
1093	DAU1591089	Sensing device
1115	DAU1591051	pressure switch 140/120
1116	DAU1590240	power cord clasper
1117	DAU1591109	PRESSURE SWITCH FOR HEATER
2001	DAU1590274	Door edge guard piece
2002	DAU1591133	INNER DOOR
2002a	DAU1590887	Cover one
2002b	DAU1590888	Cover two

2002ckit	DAU1590002	Covers for new fan assembly (cover for old fan assembly is not available)
2004	DAU1590116	Dispenser bracket
2005	DAU1590401	DISPENSER
2006	DAU1590799	Wiring harness
2008	DAU1590060	RING
2009	DAU1590018	LEFT HINGE
2010	DAU1590082	Joint pin
2011	DAU1590019	RIGHT HINGE
2012	DAU1590086	DOOR HINGE
2013	DAU1590055	Door spring
2015	DAU1590074	Screw M5 X 10
2016	DAU1590076	Nut M5
2017	DAU1590791	Outer door
2018	DAU1590152	FRONT PANEL
2023	DAU1590383	HANDLE ASSY
2024	DAU1590319	Door switch
2027	DAU1591050	Power switch
2028	DAU1590326	Red pilot lamp
2034	DAU1590340	CONTROL BOARD
2035	DAU1590007	Control panel film
2036	DAU1590282	CONTROL BOARD BOX
2039	DAU1590391	Window
2040	DAU1590265	Screw sleeve
2041	DAU1590153	Sleeve cover
2048	DAU1590727	FAN ASSEMBLY
2053	DAU1590292	Control panel cover
2080	DAU1590004	button spring
2950	DAU1590805	Power button
2951	DAU1590161	Program key
3001	DAU1591033	Left side panel
3003	DAU1590132	Left uprights
3005	DAU1590094	Upper rear crosspiece
3006	DAU1590228	Door clamp
3007	DAU1590091	Door lock
3009	DAU1590790	Upper front crosspiece
3010	DAU1591044	TANK GASKET
3011	DAU1590133	Right uprights

3012	DAU1590035	Right side panel
3013	DAU1590224	Cup rack
3014+5+6	DAU1591047	Cutlery basket assembly
3017	DAU1590072	LOWER BASKET
3018	DAU1591055	UPPER BASKET
3019	DAU1590349	Sound-proof felt
3021	DAU1591041	Guide rail block
3022	DAU1590117	Guide rail
3023	DAU1591127	RAIL SUPPORT ASSY
3027	DAU1590092	Lower front crosspiece
3029	DAU1590131	Base board
3031	DAU1590792	TANK ASSEMBLY
3032	DAU1590260	Tank band bracing block
3033	DAU1590105	Lower rear crosspiece
3034	DAU1590102	Middle rear crosspiece
3035	DAU1590851	Ration spoon
3036	DAU1590232	Left claw
3037	DAU1590231	Right claw
3038	DAU1590235	Framework support
3039	DAU1590081	Orientation pole
3040	DAU1590266	Adjustable basket handle
3041	DAU1590073	Slip bracket
3042+43	DAU1591071	Basket wheel + wheel shaft
3044	DAU1590104	Right piece of adjustable base board
3046	DAU1590103	Left piece of adjustable base board
3047	DAU1590788	left Holder of adjustable base boar
3047	DAU1590789	right Holder of adjustable base board
3048	DAU1590749	Adjust steel rope
3049	DAU1590138	Adjust nut
3050	DAU1590221	Top board hook
3051	DAU1590079	Adjust screw
3052	DAU1590234	Right adjuster holder assembly
3053	DAU1590020	Front foot
3054	DAU1590301	slide
3055	DAU1590078	Adjustable pole
3056	DAU1590233	Left adjuster holder assembly
3057	DAU1590087	Back foot
3079	DAU1590795	3 in 1 tablet container