







Position	Code	description
0	103085	FILTER
01	411F6D1Z	Right side panel
02	35MF60001H	Interior control panel
04	053074	Upper seal
05	51BF601DH	Right front trim
06	053087	SEAL
07	411F602.1	Bottom panel
08	08328400A	Lower trim
09	51BF601SH	Left front trim
10	094390	Door hinge (female)
11	411F6S1Z	Left side panel
13	411F603	REAR PANEL
14	040056	Rubber
16	411F607	Lower air conveyor
17	079017	Tangential fan
18	411F604	Upper shelter
20	411F605	Air conveyor
21	421F602Z	Conveyor support
23	032F62207	GLASS
24	NOCODE01	NOT AVAILABLE
25	51BF604	Handle bar
26	0372260OT	HANDLE
27	032F62208	GLASS
28	063107	Hinge (male)
29	375FF6013	Door panel with inner glass
30	0850830OT	BUSH
37	218000O252	KNOB
38	073048.1	LAMP
39	07306201	Control lamp cover - Orange
40	073039.2	Control lamp L 230
41	07306202	Control lamp cover - Red
42	050030	Oven switch
43	066141	THERMOSTAT
44	2183442308	KNOB
45	074057/1	TIMER
46	072006	LAMP HOLDER
47	073013001	LAMP

48	066140	Cut-off thermostat 175 degree
49	062089004	Top + grill element - 230 V
50	47AF601G	Fan diffuser
52	062090004	Bottom element - 230 V
53	094395	Plaque
54	079008001F	Fan motor - 230 V
55	213025	CLIP
56	217646	Shelf support
57	001142	Shelf support screw
58	48BF601G	Oven tray
59	217527	GRID
60	051079	Terminal Block