







Position	Code	description
01	411F6D1Z	Right side panel
03	51BF614S.1	Deflector
04	053074	Upper seal
05	51BF601DH	Right front trim
06	053087	SEAL
07	411F602.1	Bottom panel
08	08328400A	Lower trim
09	51BF601SH	Left front trim
10	094390	Door hinge (female)
11	411F6S1Z	Left side panel
13	411F603	REAR PANEL
14	040056	Rubber
16	411F607	Lower air conveyor
17	079017	Tangential fan
18	411F604	Upper shelter
20	411F605	Air conveyor
21	421F602Z	Conveyor support
22	NOCODE01	NOT AVAILABLE
23	35F6C08SD3	FRONT PIECE
25	51BF604	Handle bar
26	037265009	Door handle
27	032F62657	GLASS
28	063107	Hinge (male)
29	375FF6013N	INNER DOOR
30	103734080	Handle plaque
38	073048.2	Control lamp L 600/230-240
39	07306201.2	Control lamp cover (Orange)
40	073039.2	Control lamp L 230
41	07306202.2	Control lamp cover (Red)
42	050030	Oven switch
43	066157	THERMOSTAT
44	2183007363	KNOB
45	074009	60 min alarm
46	072006	LAMP HOLDER
47	073013001	LAMP
048A	066056	Cut-off thermostat 120 degree
048B	066145	Cut-off thermostat 80 degrees

49	062089004	Top + grill element - 230 V
50	47AF602G	Fan diffuser
52	062090004	Bottom element - 230 V
53	094395	Plaque
54	079008001F	Fan motor - 230 V
55	213025	CLIP
58	48BF601G	Oven tray
59	217603	WIRE SHELF
60	0510146	TERMINAL BOARD
61	103948	Switch spacer
62	030136.1	Fan motor insulation