










Position	Code	description
1= 1.1	0329E031	OVEN DOOR GLASS
2= 1.2	0312813	INNER DOOR GLASS
3= 1.3	063135DX	HINGE MALE RIGHT
4= 1.4	063135SX	HINGE MALE LEFT
5= 1.5	037292061	OVEN DOOR HANDLE
6= 1.6	069095	Corner door lower right
7= 1.7	069096	Corner door lower left
8= 1.8	069097	Retainer door glass
9= 1.9	069098	Support door glass
10= 1.10	51BF904A	LOWER BAR
11= 2.1	0329E030	GLASS FACIA PANEL
12= 2.2	35M9E007A	INTERIOR CONTROL PANEL
13= 2.3	218900A521	KNOB
14= 2.4	050062	Oven switch (see tech bulletin AUNZ0155 for wiring connections)
15= 2.5	066078	THERMOSTAT
16= 2.6	074103	PROGRAMMER
17= 2.7	094657	BRACKET
18= 2.8	040056	Rubber
19= 2.9	073090	Control lamp cover (Blue)
20= 2.10	2180009478	KNOB GOBLET
21= 2.11	1031299	RING GOBLET
22= 2.12	094795	GOBLET BRACKET
23= 3.1	450F91EM42	Oven frame
24= 3.2	45BF9003G	BODY FRONT PANEL
25= 3.3	053179	SEAL
25b= 3.3	053162	SEAL (OPEN GASKET)
26= 3.4	35M9E002A	INTERIOR CONTROL PANEL
27= 3.5	411F915	RIGHT SIDE PANEL
28= 3.6	411F905	LEFT SIDE PANEL
29= 3.7	063130	Door hinge (female)
30= 3.8	094744DX	RIGHT BRACKET
31= 3.9	094744SX	LEFT BRACKET
32= 3.10	411F901	LOWER SHELTER
33= 3.11	08333100A	LOWER TRIM
34= 3.12	51BF907	SUPPORT BAR
35= 3.13	51BF909	MOTOR SUPPORT

36= 3.14	030219	Oven insulation
37= 3.15	030242	Rear insulation
38= 3.16	51BF906A	FRONT TRIM
39= 3.18	411F913	REAR SHELTER
40= 3.19	51BF910	REAR SUPPORT
41= 3.20	421F905Z	LOWER SHELTER
42= 3.21	421F909Z	PANEL VENTING MIDDLE
43= 3.22	079054	TANGENTIAL FAN
44= 3.23	51BF915	REAR BRACKET
45= 3.24	411F914	UPPER SHELTER
46= 3.25	040041001	PLUG
47= 3.26	08333400H	LOWER TRIM
48= 3.27	1031234	SPACER
49= 3.28	214005	NUT
50= 3.29	08333300H	MIDDLE TRIM
51= 3.30	08333200H	TOP TRIM
52= 4.1	062157004	Top + grill element
53= 4.2	062097004	Fan element
54= 4.3	062146004	Bottom element
55= 4.4a	073103	LAMP
56= 4.4b	072026	LAMP HOLDER
57= 4.5	079049	Fan motor 230 V
58= 4.6	51BF911	SUPPORT BAR
59= 4.7	1031283	Element support
60= 4.8	421F908Z	LOWER PROTECTION
61= 4.9	47AF9020	Fan diffuser
62= 4.10	051072	TERMINAL BLOCK
63= 4.11	051049	Terminal block 25A-3P
64= 4.12	1132168	WIRING
65= 4.13	054041	CORD
66= 4.14	073039.2	Control lamp L 230
67= 4.15	066068	Cut-off thermostat 130 degree
68= 4.15	066145	Cut-off thermostat 80 degrees
69= 5.1	217659	Shelf support
70= 5.2	001142	Shelf support screw
71= 5.3	48BF902G	Oven tray
72= 5.4	217651	Grill pan grid
73= 5.5	217657	FLAT SHELF

74= 5.6	217650	OVEN SHELF
75= 5.7	037224.1	GRILL-PAN GRID HANDLE
76= 5.10	080037	Rotisserie spear (including handle)
77= 5.11	001162	SCREW
78= 5.12	085113	Douille
79= 5.13	094671	Equerre
80= 5.14	079053	Rotisserie motor
81= 5.15	217652	Rotisserie support
82= 5.16	085109	Rotisserie screw
83= 5.17	085110	Rotisserie bush
84= 5.18	473140	RIGHT CATALYTIC PANEL
85= 5.19	473150	LEFT CATALYTIC PANEL
86= 5.20	103085	FILTER
87= 5.21	037012	Spear handle