










Universalschüssel - Food Processor Bowl



Metalltopf - Metal Bowl



Mixer - Liquidiser goblet



Position	Code	description
2	7322000474	SWITCH KNOB
3	BR67051456	GEAR
4	7322000374	RING
5	BR67002508	SPRING
6	7322000454	COVER
7	BR63210639	SWITCH CAM
8	BR67002506	LEVER
9	BR67051068	SPRING
12	7322000414	POWER SUPPLY CORD (GB)
13	7322000424	PCB (220/240V 50/60Hz)
14	BR67000047	COUPLING
15	BR67050087	PIN
16	BR67000297	WASHER (82X12X05)
17	BR67000048	EXTERNAL DRAGGER DISC
18	BR67051072	WASHER (28X213X05)
19	7322000444	BODY
21	BR67051249	AIR DUCT
22	BR67051250	AIR DUCT
23	BR63210623	ICS 3210 KM3050 MOTOR 220-240V 50-60Hz 800-900W 14.000RPM
24	BR67000978	CARBON BRUSH
25	BR63210643	WIRING SET
26	BR67050886	FRAME
27	BR67001120	RUBBER PAD
28	BR67051251	Fan motor cpl.
31	BR67000262	SCREW (42X13)
32	BR63210655	PULLEY
33	BR67002511	BEARING
34	BR67002512	SUPPORT
35	BR67000539	TENSION ROLLER
36	BR67002509	BELT
37	BR67002510	BELT
39	BR67051071	PINION
40	7322000434	SUPPORT BASE
41	BR67000261	BOTTOM SCREW
42	BR67000260	SCREW (32X19)
43	7322000394	FOOT

51	BR67000545	COVER
52	BR63210652	CONTAINER
53	BR63210629	UNIVERSAL KNIFE
54	BR67000528	PROTECTION
65	BR67051256	WHISK
66	BR67051257	WHISK
71	BR63210634	FRENCH FRIES CUTTER KD VERP.r
72	BR63210635	JULIENNE DISC
73	BR63210631	GRATER DISC
74	BR63210632	SLICING DISC
75	BR63210633	SHREDDING DISC
76	BR67000546	SUPPORT
77	BR67051258	DISC HOLDER
78	BR67051073	TAMPER
81	BR67051259	SPATULA
85	BR67000052	FUNNEL
86	BR67000053	CONTAINER LID
87	7322000464	BOWL
88	BR67051262	KNEADER HOOK (4 KG)
89	BR67051263	MIXER ARM
91	BR67051264	CHOPPER LID
92	BR67002514	Sealing
93	BR67051265	MIXER BLADE
94	BR67051266	CHOPPER INSERT
95	BR67002513	Sealing
96	BR63210626	BR63210626
97	BR67051267	BLENDER RING
98	BR67000530	RING NUT
1001	BR67051112	Press punch for coupling 60x16 mm
1003	BR67051455	Hand held meter (DEUMO)
1004	BR64889119	DISC COUPLING
1005	BR64889120	COVER DISASSEMBLY TOOL