



1




3




4

only MQ787




5

6




2



10

11



7



8




9




only MQ745

1.250 ml


20




21



24



22



23



100

only MQ735

MQ725/745/785/787

all - except
MQ700 (Soup)

500 ml

350 ml

50

20

40

103

101

102

31

41




51

32

42

33


43



1500 ml


80

81




104


82



90



91




inklusive/inclusive

83

85


86

89



92

93



only MQ787

Position	Code	description
1	7322115254	POWER HANDLE (AR)
2	7322110294	BLADE ASSEMBLY
3	BR67050811	JOINT
4	7322112244	GEAR
5	7322112264	BODY
7	7322112284	MASHER DRIVE COUPLING
8	7322112294	NUT
9	7322112274	MASHER WINGS
10	AS00004193	COVER
11	AS00004187	BEAKER PLASTIC
40	AS00005266	UPPER COUPLING
41	AS00006077	BLADE
42	AS00004190	CONTAINER
43	AS00005952	RING
50	7322111294	GEAR GROUP
51	AS00004189	WHISK
80	7322111254	TAMPER
81	7322111274	UPPER COUPLING
82	BR67051017	BLADE
83	BR67051214	BLADE
85	BR67051215	BLADE
86	BR67051019	BLADE
89	BR67051020	SUPPORT
90	BR67051021	CONTAINER (1500 ml)
91	7322111234	COVER
92	BR67051424	BLADE
93	7322114874	FRENCH FRIES CUTTER