







2/1.AS



2/2.CA



2/3.B



2/5.H

Position	Code	description
1= 1.1	330I54031	Hob top
2= 1.2	35P18803DL	CONTROL PANEL
3= 1.5	040026	Top grate buffer
4= 1.7	217415	Pan-stand
5= 1.9	4116332	Burner casing
6= 1.10	053037	SEAL
7= 1.11	094154	Fixing bracket
8= 1.12	001130	SCREW
9= 1.14	094089	Burner housing
10= 1.15	215191	A burner
11= 1.16	215197	SR burner
12= 1.17	215193	R burner
13= 1.18	215195	Double ring burner
14= 1.21	217299	Wok support
15= 1.25a	103118035	Plug (White)
16= 1.25b	103118002	Plug (Black)
17= 1.26	094101	BRACKET
18= 1.27	103120	PROTECTION
19= 1.29	217303	Grate for small pans
20= 1.30	001024	SCREW
21= 1.31	085049	Spacing
22= 1.32	001021	SCREW
23= 1.37	094295	Spacing
24= 2.1	218A00355M	Knob (White)
25= 2.2a	106041	Tap - diameter 0.25 SR - A
26= 2.2b	106042	Tap - diameter 0.34 R
27= 2.2c	106043	Tap - diameter 0.35 UR
28= 2.2d	106076	Tap - diameter 0.40 DR
29= 2.3a	101075	Injector - diameter 0.47
30= 2.3b	101119	Injector - diameter 0.60
31= 2.3c	101082	Injector - diameter 0.76
32= 2.3d	101089	Injector - diameter 0.90
33= 2.3e	101069	Injector - diameter 0.83
34= 2.3f	101066	Injector - diameter 0.70
35= 2.3g	101129	Injector - diameter 1.15
36= 2.3h	101074	Injector - diameter 1.35
37= 2.3i	101167	Injector - diameter 1.45

38= 2.4	3426340G02	4 gas inlet pipe
39= 2.5	094088004	Tap bracket (4 gas)
40= 2.6	001060	SCREW
41= 2.8	053024.1	Sealing washer
42= 2.9	067008	Elbow
43= 2.12	067026	Conical adaptor
44= 2.16	103347	Gas pressure regulator 1/2
45= 2.17	094085	Inlet pipe fixing bracket
46= 3.1a	068060001	Burner-head A
47= 3.1b	068061001	Burner-head SR
48= 3.1c	068062001	Burner-head R
49= 3.1d	068063001	Burner-head UR
50= 3.2a	216005011	Burner-cap ring A (Brass)
51= 3.2b	216006020	Burner-cap ring SR (Brass)
52= 3.2c	216007024	Burner-cap ring R (Brass)
53= 3.2d	216008022	Burner-cap ring UR (Brass)
54= 3.3a	216078080	Burner-cap A (Black)
55= 3.3b	216079080	Burner-cap SR (Black)
56= 3.3c	216089508	SPART.R 24FORI D3 GH.GRIG
57= 3.3d	216081080	Burner-cap UR (Black)
58= 3.4	068075001A	Double ring burner-head
59= 3.5	216100040	Double ring burner-cap (Brass)
60= 3.6	216074030S	Double ring burner-cap ring (Brass)
61= 3.7	216070080	Double ring burner-cap (Black)
62= 5.1	051036	Terminal block 16A-2P PA 44-2FV
63= 5.2	052001	Wire fastener
64= 5.5	054055	Cord with plug 3x0.75
65= 5.6a	084007	Spark plug - 400 mm
66= 5.6b	084014	Spark plug - 1050 mm
68= 5.7	035033	Spark plug spring
69= 5.8	082047.1	Ignition coil
70= 5.9a	081033	Ignition push-button (White)
71= 5.9b	081032	Ignition push-button (Black)
72= 5.19	077026	Ignition switch
73= 5.14	003023	Snap ring