




Position	Code	description
01	2183007363	KNOB
02	3553C61	Glass with frame
03	050033	Normal/rapid electric plate switch
05	04782230	COPP 3C D155 1200W 230V (EGONOMIC)
06	04775230	3 circuit hotplate - diameter 180 - 1800W
07	053055	Switch gasket
008A	073028	Control lamp L470
008B	073043	Control lamp L 200
009A	073059	Control lamp cover (Red)
009B	073060	Control lamp cover (Orange)
10	4113C05	CASING
11	094347	Front fixing bracket (to fix the appliance to the cabinet)
12	001069	SCREW
13	051079	Terminal Block
15	053065	SEAL
16	NOCODE01	NOT AVAILABLE