




Position	Code	description
01	3213F1S	Lid
03	103492	Oil tray
04	218G00X333	KNOB
005A	073059	Control lamp cover (Red)
005B	073060	Control lamp cover (Orange)
06	053079	Knob rubber
08	333F014SDA	WORK TOP
09	073043	Control lamp L 200
10	053055	Switch gasket
11	NOCODE01	NOT AVAILABLE
12	050058	Knob switch
14	4113F02S	CASING
15	094347	Front fixing bracket (to fix the appliance to the cabinet)
16	001069	SCREW
17	051079	Terminal Block
18	066137	Safety thermostat
19	4113F01	TRAY
21	053024.1	Sealing washer
22	053065	SEAL
23	053081	GASKET
25	035096	SPRING
26	103534	BALL
27	071057	BOLT
28	4933F001	HEATING ELEMENT
30	003056	O RING
31	062084004	HEATING ELEMENT