




Position	Code	description
01	3D61401SD1	HOB TOP P61
02	411P6101	Burner casing
03	001085	Gas tap fixing screw
04	094347	Front fixing bracket (to fix the appliance to the cabinet)
05	001217	SCREW
06	094335	Fixing bracket
07	217724	RH trivet
08	217729	Wok pan adapter
10	0291156	Left burner pipe SR
11	0291154	Burner pipe A
12	0291157	Burner pipe MW
13	0291155	Right burner pipe SR
016A	106309GN	Tap diam 0.33 - A- DB (inner)
016B	106310GN	Tap diam 0.34 - SR
016C	106312GN	Tap diam 0.64 - DB (outer)
17	10316760A	Knob ring
20	218E00H550	KNOB
21	040057	Rubber joint
22	342P614001	4 gas inlet pipe
23	067008	Elbow
24	053024.1	Sealing washer
25a	215496	Burner-cup A
25b	215497	Burner-cup SR
25c	215517	Burner-cup MW
026A	101410	Injector diam 0.92 - A (NG)
026B	101367	Injector diam 1.17 - SR
026C	101407	Injector diam 1.48 - MW (NG)
026D	101408	Injector diam 0.56 - A
026E	101358	Injector diam 0.70 - SR
026F	101406	Injector diam 0.88 - MW (ULPG)
27a	068131003	Burner head A
27b	068132003	Burner head SR
27c	068145003	Burner-head MW
28a	216153005A	Burner-cap A
28b	216154005A	Burner-cap SR
28c	216167005A	Burner-cap inside MW
28d	216168005A	Burner-cap outside MW

035A	084058	Spark plug L = 250 mm
035B	084060	Spark plug L = 500 mm
035C	084077	Spark plug MW - L = 520 mm
036A	035125	Igniter spring
036B	035127	Igniter spring TR
37	082082	Electronic ignition
38	660131046	Terminal block + power cord with plug 3x0.75 mm ²
041A	107078	Burner thermocouple L = 600
041B	107089	Burner thermocouple L = 250
041C	107098	Thermocouple MW - L = 300 mm
42	214079	Thermocouple nut
45	103389	Cable L = 400
46	003094	RETAINING RING
49	1031469	Ignition switches
50	094627	Burner support A
51	094628	Burner support SR
52	094831	Burner support MW
53	067026	Conical adaptor
54	103468	Test point adaptor
55	103347	Gas pressure regulator 1/2