




Position	Code	description
1=1.1	336D041SD2	Hob top
2=1.2	4116D03	Burner casing
3=1.3	053065	SEAL
4=1.5	001221	SCREW
5=1.7	094338	Fixing bracket
6=1.11	094345	BRACKET
7=1.12	094786	Terminal block protection
8=1.16	10348100X	PLUG
9=1.22	58B6303	Bar
10=4.1	218E00H550	KNOB
11=4.2	050086	Normal/rapid electric plate switch
12=4.3	04725230	Normal electric plate diam 145 - 1000 W - 230 V
13=4.3	04726230	Normal electric plate diam 180 - 1500 W - 230 V
14=4.3	103084R	Normal/rapid plate protection diam 145
15=4.4	103081R	Normal/rapid plate protection diam 180
16=4.6	053055	Switch gasket
17=4.8	214055	NUT
18=4.11	04727230	Rapid electric plate diam 145 - 1500 W - 230 V
19=4.11	04763230	Rapid electric plate diam 180 - 2000 W - 230 V
20=5.1	1132257	WIRING
21=5.2	051068	Terminal block
22=5.3	073058	Control lamp L 230
23=5.4	073057	Control lamp cover