






Position	Code	description
1= 0a	6107050007	Natural gas conversion kit
2= 01	032G7021	Hob top
3= 02	10315241CD	CONTROL PANEL
4= 03	053076	SEAL
5= 04	040087	Rubber joint
6= 05	218E00H554	CONTROL KNOB
7= 06a	053136	Burner gasket A
8= 06b	053137	Burner gasket SR
9= 06c	053138	Burner gasket R
10= 07	053107	Burner gasket
11= 08a	068121035A	Burner-head A
12= 08b	068122035A	Burner-head SR
13= 08c	068123035A	Burner-head R
14= 09	068138035A	Burner-head
15= 10a	51BPG01A	Burner flange A
16= 10b	51BPG02A	Burner flange
17= 10c	51BPG03A	Burner flange R
18= 11	51BPG07A	Burner flange
19= 12a	216140005A	Burner-cap A
20= 12b	216141005A	Burner-cap SR
21= 12c	216142005A	Burner-cap R
22= 13	216160005A	Burner-cap outside
23= 14	216161005A	Burner-cap inside
24= 15	217642	Top grate
25= 16	217643	Top grate
26= 17	217498	Grid for woks
27= 18	067026	Conical adaptor
28= 21	0291051	Inlet pipe - central TR
29= 22	0291050	Inlet pipe - rear right SR
30= 23	0291052	Inlet pipe - rear left SR
31= 24	0291053	Inlet pipe R
32= 25	0291049	Inlet pipe A
33= 26a	035129	Burner spring A
34= 26b	035120	Burner spring SR
35= 26c	035121	Burner spring R
36= 27	035122	Burner spring
37= 28	085102	Burner bush

38= 30a	107064	Burner thermocouple L = 250
39= 30c	107057	Burner thermocouple L = 450
40= 30d	107067	Burner thermocouple L = 500 mm
41= 31	214057	NUT
42= 32a	101262	Injector ULPG Ø 0.53 - A
43= 32b	101263	Injector ULPG Ø 0.70 - SR
44= 32c	101244	Injector Rapid diam 0.91 - LPG
45= 32d	101233	Injector ULPG Ø 0.95 - TR
46= 32e	101182	Injector NATURAL GAS Ø 0.85 - A
47= 32f	101260	Injector NATURAL GAS Ø 1.12 - SR
48= 32g	101273	Injector Rapid diam 1.45 - NG
49= 32h	101335	Injector NATURAL GAS Ø 1.60 - TR
50= 33a	215486	Burner-cup A
51= 33b	215487	Burner-cup SR
52= 33c	215488	Burner-cup R
53= 34	215489	Burner cup
54= 35a	084028	Spark plug L=250mm (auxiliary burner)
55= 35b	084029	Spark plug L=630mm (semirapid &
56= 35c	084046	Spark plug L = 400
57= 36	035094	Igniter spring
58= 37	342G750003	5 gas inlet pipe
59= 38a	106249	Tap Auxiliary diam 0.27
60= 38b	106252	Tap Semi-rapid diam 0.34
61= 38c	106253	Tap Rapid diam 0.44
62= 38d	106254	Tap Triple-ring diam 0.65
63= 39	001202	SCREW
64= 40	067008	Elbow
65= 41	053024.1	Sealing washer
66= 42	094616	Tap bracket
67= 43	411G702	Burner casing
68= 44	1031126	Ignition switches
69= 45	094794	Burner bracket A
70= 46	094716	Burner bracket SR
71= 47	094717	Burner bracket R
72= 48	094718	Burner bracket
73= 49	051079	Terminal Block
74= 50	054131	Cord 3x0.75
75= 51	001217	SCREW

76= 52	094389	BRACKET
77= 53	094389	BRACKET
78= 55	6300088	KIT IGNITION COIL
79= 56	103468	Test point adaptor
80= 57	103347	Gas pressure regulator 1/2