




Position	Code	description
0	EI1205	Bottom grill
1	EI1082	Top cover part
2	EI1001	Left door upper hinge
3	EI1147	Display Board(Left) model DG3-1033 (50EB-1.4.1)
4	EI1084	Display Board(Right) model DG3-1033 (50EB-1.4.1)
5	EI1003	Right door upper hinge
6	EI1098	Door hinge centre
7	EI1005	Rail (18inch)
8	EI1006	Shelf
9	EI1099	Upper windway plate
10	EI1052	LAMP COVER
11	EI1049	Electrical box cover
12	EI1068	Led Lamp
13	EI1085	PCB and 2 displays assembly version DG3-1033 (50EB-1.4.1)
14	EI1012	TRANSFORMER
15	EI1015	Fan net
16	EI1014	Fan for evaporator
17	EI1257	DG22-316 AIRWAY BOARD
18	EI1035	Thermistor cover
19	EI1036	Thermistor (air sensor)
20	EI1017	Evaporator foam
21	EI1047	Thermistor (defrost sensor)
22	EI1018	EVAPORATOR
23	EI1019	Assembly pipe
24	EI1021	Drier
25	EI1022	Condenser
26	EI1023	COMPRESSOR
27	EI1024	JUNCTION BOX
28	EI1025	Power line
29	EI1026	Terminal Plate
30	EI1027	Compressor support plate
31	EI1065	Fan (see technical info.)
32	EI1029	Fan Bracket Outside
33	EI1030	Compressor connecting pipe
34	EI1031	Water drip tray
35	EI1032	Feet

36	EI1204	SUPP BRACKET OF FRONT LEGS
37	EI1034	Decorative Frame
38	EI1258	DG18-80 HEATER AIRWAY-BOARD FOAM
39	EI1102	Drainage pipe
40	EI1093	Water tray
41	EI1090	HEATER
42	EI1091	Heater Insulation Board
43	EI1092	Heater Fan
44	EI1094	Heater Fan Mesh
45	EI1259	DG22-314 LOWER MIDDLE AIR-DUCT BOARD
46	EI1260	DG18-1043.1 MIDDLE AIR-DUCT FOAM
47	EI1038	12 inch roller
48	EI1039	Shelf WE2
49	EI1037	WB support
50	EI1040	DOOR
51	EI1041	Right lower hinge
52	EI1042	Door hinge centre
53	EI1043	Keylock
54	EI1044	Left lower door hinge
55	EI1045	HANDLE