




Position	Code	description
1	EI1082	Top cover part
2	EI1001	Left door upper hinge
5	EI1003	Right door upper hinge
6	EI1004	Door hinge centre
7	EI1050	LED light
8a	EI1143	PCB and 2 displays assembly version DG3-1043
8b	EI1085	PCB and 2 displays assembly version DG3-1033 (50EB-1.4.1)
9	EI1012	TRANSFORMER
11	EI1052	LAMP COVER
12	EI1086	Upper wind way part
13	EI1015	Fan net
14	EI1087	Mid wind way support
15	EI1088	Wind way part
16	EI1071	Condenser foaming
17	EI1014	Fan for evaporator
18	EI1047	Thermistor (defrost sensor)
19	EI1072	EVAPORATOR
20	EI1062	Air-Circulating Pipe
21	EI1073	Condenser
22	EI1031	Water drip tray
23	EI1065	Fan (see technical info.)
25	EI1030	Compressor connecting pipe
26	EI1021	Drier
27	EI1074	COMPRESSOR
29	EI1024	JUNCTION BOX
30	EI1026	Terminal Plate
31	EI1075	Compressor support plate
32	EI1064	Feet
33	EI1076	Front cabinet support plate
34	EI1205	Bottom grill
35	EI1089	Heater Foam
36	EI1090	HEATER
38	EI1092	Heater Fan
40	EI1094	Heater Fan Mesh
41	EI1095	Mid wind way part
43	EI1036	Thermistor (air sensor)

44	EI1078	ROLLER
45	EI1079	WP support
48	EI1123	DOOR
49	EI1058	Right lower door hinge
50	EI1042	Door hinge centre
51	EI1043	Keylock
52	EI1059	Lower left door hinge
53	EI1056	HANDLE